PHILIPS

Universal counters PM 6611

9446 066 110.1

PM 6613

9446 066 130.1

PM 6614

9446 066 140.1

PM 6615

9446 066 150.1

Ordering number of this manual 9499 460 07702

751215/1/2

PHILIPS

PHILIPS

PM 6611

9446 066 110.1

PM 6613

9446 066 130.1

Instruction manual
Anleitung
Notice d'emploi et d'entretien

PM 6614

9446 066 140.1

PM 6615

9446 066 150.1

Ordering number of this manual
9499 460 07702

751215/1/2

IMPORTANT

In correspondence concerning this instrument, please quote the type number and the serial number as given on the type plate on the rear of the instrument.

WICHTIG

Beim Schriftwechsel über dieses Gerät gebeten, die genaue Typenbezeichnung und Seriennummer anzugeben. Diese befinden sich auf dem Typenschild an der Rückseite des Gerätes.

IMPORTANT

Dans votre correspondance et dans vos réclamations se rapportant à cet appareil, veuillez TOUJOURS indiquer le n° de type et le n° de série que son marquées sur la plaquette de caractéristiques fixée sur la paroi arrière de l'appareil.

© N.V. PHILIPS' GLOEILAMPENFABRIEKEN — EINDHOVEN — THE NETHERLANDS — 1975

Printed in Sweden / Be-Te Tryck i Solna AB

CONTENTS

General information

I. Introduction 7

II. Technical data 7

III. Accessories 10

Directions for use

IV. Installation 11

1. Mains voltage conversion 11
2. Earthing 11
3. Fuses 11
4. Optional accessories 11

V. Controls and indicators 12

VI. Operation 14

General information

1. Switch on power 14
2. Warm up time 14
3. External frequency standard 14

Measurements

4. CHECK 15
5. FREQUENCY A 15
6. FREQUENCY B 15
7. PERIOD A 15
8. RATIO A/C 15
9. RATIO B/C 15
10. COUNT A 15

Service manual

List of figures

Figure IV-1. Mains transformer connections 11

Figure VI-1. Front panel PM 6611 42

Figure VI-2. Front panel PM 6613, PM 6614 and PM 6615. 42

Figure VI-3. Rear panel 43

Figure VI-4. Top view 43

Figure VI-5. Bottom view 43

INHALT

Allgemein

I. Einleitung 19
II. Technische Daten 19
III. Zubehör 22

Gebrauchsanleitung

IV. Installation 23
1. Einstellen der Netzspannung 23
2. Erdung 23
3. Sicherungen 23
4. Wahlweises Zubehör 23
V. Bedienungsorgane und Anschlüsse 24
VI. Betrieb 26

Allgemeines

1. Inbetriebnahme 26
2. Aufwärmzeit 26
3. Externe Frequenz-Standards 26

Messungen

4. EIGENKONTROLLE 27
5. FREQUENZ A 27
6. FREQUENZ B 27
7. PERIODENDAUER A 27
8. FREQUENZVERHÄLTNIS A/C 27
9. FREQUENZVERHÄLTNIS B/C 27
10. IMPULSZÄHLUNG 27

Kundendienstanleitung (nur in englischer Sprache) 47

Verzeichnis der Abbildungen

Abbildung IV-1. Netztrafoanschlüsse 23
Abbildung VI-1. Frontseite PM 6611 42
Abbildung VI-2. Frontseite PM 6613, PM 6614 und PM 6615 42
Abbildung VI-3. Rückseite 43
Abbildung VI-4. Ansicht von oben 43
Abbildung VI-5. Unteransicht 43

TABLE DES MATIÈRES

Generalites

I. Introduction 31
II. Caractéristiques techniques 31
III. Accessoires 34

Mode d'emploi

IV. Installation 35
1. Adaption à la tension secteur 35
2. Mise à la terre 35
3. Fusibles 35
4. Accessoires optionnels 35
V. Organes de commande, indicateurs et raccords 36
VI. Manipulation 38

Generalites

1. Mise en route 38
2. Temps d'échauffement 38
3. Frequences externes standard 38

Mesures

4. CONTRÔLE 39
5. FREQ. A 39
6. FREQ. B 39
7. PERIOD A 39
8. RAPPORT DE FREQUENCE A/C 39
9. RAPPORT DE FREQUENCE B/C 39
10. TOTALISATION (COUNT A) 39

Notice d'entretien (uniquement publiée en langue anglaise) 47

Liste des figures

Figure IV-1. Connexions du transformateur secteur 35
Figure VI-1. Vue avant PM 6611 42
Figure VI-2. Vue avant PM 6613, PM 6614 et PM 6615 42
Figure VI-3. Vue arrière 43
Figure VI-4. Vue dessus 43
Figure VI-5. Vue dessous 43

I. INTRODUCTION GENERAL INFORMATION

The counters in the PM 6610-series have frequency ranges from 10 Hz up to 80 MHz, 250 MHz, 520 MHz and 1 GHz respectively for the PM 6611, PM 6613, PM 6614 and PM 6615.
The VHF and UHF counters PM 6613, PM 6614 and PM 6615 offer two different signal inputs for RF- and LF-signals.
All models can measure frequency, period, ratio and have a totalizing mode.
Optional accessories such as four different oscillators, a battery unit, a BCD output unit and a D/A converter extend the field of application.

II. TECHNICAL DATA

Properties expressed in numerical values with statement of tolerances are guaranteed. Numerical values without tolerances are intended for information purposes only and indicate the properties of an average instrument. The numerical values hold good for the nominal mains voltage.

A. MEASUREMENTS

Frequency

Range	10 Hz—80 MHz, PM 6611 10 Hz—250 MHz, PM 6613 10 Hz—520 MHz, PM 6614 10 Hz—1000 MHz, PM 6615
Gate times	10 ms,100 ms, 1 s and 10 s, INPUT A The gate time is multiplied with a prescaling factor if input B is used.
Resolution	100 Hz, 10 Hz, 1 Hz and 0.1 Hz
Accuracy	± 1 count ± time base error

Single period A

Range	100 ns—100 s
Frequency counted	10 MHz
Time resolution	100 ns
Accuracy	± 1 count ± trigger error* ± time base error

---

* Trigger error is $\leqq 3 \times 10^{-3}$ for signals with signal to noise ratio of $\geqq$ 40dB.

Period average A

Range	Sine wave: 10 Hz—10 MHz pulses: 1 Hz—10 MHz
Frequency counted	10 MHz
Number of averagings	$N = 10^2$ and 10^4 with correct decimal point positioning
Time resolution	$\frac{100\ ns}{N}$
Accuracy	± 1 count ± trigger error/N* ± time base error

Count A

Range	1 to 999999999
Mode	Accumulates pulses during manual start — stop interval
Pulse pair resolution	12 ns

Frequency ratio A/C or B/C

Range	f_A : 10 Hz—80 MHz (All models) f_B : 5— 250 MHz, PM 6613 50— 520 MHz, PM 6614 50—1000 MHz, PM 6615 f_C : 1 kHz—10 MHz (All models)
Multiplier	$N = 10^2$ and 10^4
Accuracy	± 1 count ± trigger error* of f_C/N
Check	10 MHz internally applied to channel A Any measuring function may be selected

Auxiliary functions

Reset	Pushing "RESET" resets the counter. Releasing "RESET" starts new measurement
Start/Stop	In function "COUNT A" the gate time is manually controlled by push-button "START/STOP". The memory is automatically switched off.
Display time	Continuously variable 0.2—5 s and infinite if display time knob is pulled
Stand by	The switch is combined with display time control. Position "STAND BY" keeps an oven oscillator heated.
Memory	Switchable by push-button "MEMORY"

B. INPUT CHARACTERISTICS

Input A

Range	10 Hz—80 MHz full range, 10 Hz—100 kHz when low-pass filter is selected by push-button "< 100 kHz"
Sensitivity	Sine wave: 10 mV_{rms}, 6 dB down at 10 Hz pulses: 30 $mV_{p\text{-}p}$ for pulse width ≧ 6 ns and rise time ≦ 1 ms
Impedance	1 MΩ//25 pF
Coupling	AC
Attenuation	Continuously variable between ×1—×400 in two ranges
Trigger mode (level)	Depending on signal duty factor: > 25%—< 75%: ~ (zero crossing) < 25%: ⎍ (on leading edge) > 75%: ⎍ (on leading edge)
Safe overload	
Attenuation ×1	max. 250 V DC or 230 V_{rms} ≦ 440 Hz > 440 Hz : falling to 12 V_{rms} at > 1 MHz
Attenuation ×20	max. 250 V DC or 230 V_{rms}

---

* Trigger error is ≦ 3×10^{-3} for signals with signal to noise ratio of ≧ 40dB.

Input B (Not present in PM 6611)	*PM 6613*	*PM 6614*	*PM 6615*
Frequency range	5—250 MHz	50—520 MHz	50—1000 MHz
Dynamic input voltage range	10 mV_{rms}—12 V_{rms} (—27 dBm—+35 dBm)	10 mV_{rms}—12 V_{rms} (—27 dBm—+35 dBm)	10 mV_{rms}*—12 V_{rms} (—27 dBm*—+35 dBm)
Impedance	50 Ω	50 Ω	50 Ω
VSWR	< 2	< 2	< 2
Coupling	AC	AC	AC
Attenuation	by automatic PIN diode attenuator, maximum 62 dB.		
Prescaling factor	4	8	16
Safe overload	12 V_{rms}	12 V_{rms}	12 V_{rms}
AM tolerance	98% at ≤ 5 kHz modulation frequency 30% at ≥ 1 MHz modulation frequency		All models

Input C (rear)	
Range	1 kHz—10 MHz
Sensitivity	500 mV_{rms}
Coupling	AC
Impedance	≈ 10 kΩ
Safe overload	50 V_{rms}
Ext. oscillator	Via Input C.

C. OUTPUT CHARACTERISTICS

10 MHz OUT	
Output frequency	Internal oscillator frequency (10 MHz)
Signal level	≈ 1 V_{rms} (open circuit)
Output impedance	Approximately 200 Ω (short-circuit proof)
Coupling	AC
Display	9 digits In-plane 7 segment gas discharge display with decimal-point indication
Gate lamp	Indicates that main gate is open and counting takes place. In stand-by position, the Gate lamp indicates that mains or battery voltage is connected

D. GENERAL CHARACTERISTICS

Oscillator	See section Accessories and the service manual
Supply	
By mains	100—130 V or 200—260 V, 50 to 400 Hz, 15—25 VA
By external battery	+11.8—+28 V, max 1 A—0.5 A at 12 V and 24 V respectively. 100 mA in STAND BY position if oven stabilized oscillator is mounted
Connector	4 mm banana connector
By internal battery option	PM 9673

* Above 960 MHz, the sensitivity of the PM 6615 might drop to 14 mV_{rms} (—24 dBm) at 1 GHz

Environmental characteristics

Temperature	
Storage	—40°C to +70°C —40°C to +50°C (With battery option PM 9673)
Operating	0°C to +50°C (0°C to +40°C with battery option PM 9673)
Mains interference:	Below CISPR
Altitude	Max. 90% RH (26°C dewpoint)
Storage Operating	15000 m (50000 ft) 5000 m (15000 ft)
Humidity	Max. 90% RH (50°C)
Shock	Meets the requirements of the IEC68 Eb recommendations
Vibration	Meets the requirements of the IEC68F recommendations

Dimensions

Width	210 mm (8.25″)
Height	89 mm (3.5″)
Depth	325 mm (12.8″)

Weight Approx. 2.8 kg (6.2 lb)

III. ACCESSORIES

1. Standard accessories supplied with the instrument

1 mains cable
1 manual
1 1.6 A fuse ,fast action
1 "115 V" label

2. Accessories to be ordered separately

2.1. Oscillators
PM 9677 Standard oscillator
PM 9678 TCXO
PM 9679 Oven-enclosed oscillator 1×10^{-7}/month
PM 9690 Oven-enclosed oscillator 1.5×10^{-9}/24 h.

2.2. Output interface units
PM 9674 BCD output unit
PM 9675 D/A converter

2.3. Input interface accessories
PM 9351 Passive measuring probe 10 MΩ./11 pF 220 MHz, attenuation 10×
PM 9353 FET probe, 1MΩ/3.5F, 220 MHz
PM 9584 Resistive mixing piece, 50 Ω, 3 BNC sockets
PM 9346 Active-probe power supply

2.4. Coaxial cables
PM 9074 50 Ω, BNC to BNC,length1 m
PM 9588 Set of 50 Ω cables, BNC to BNC:
5 cables, length 20.7 cm
4 cables, length 40.5 cm
3 cables, length 60.3 cm
3 cables, length 198.6 cm

2.5. Mains cable
PM 9011 3-core detachable mains cable

2.6. 19″-rack mount adapter
PM 9669/01 for one counter
PM 9669/02 for two counters

2.7. Battery unit
PM 9673 Internal battery unit

2.8. Carrying case
PM 9672 Carrying case for the instrument

IV. INSTALLATION

1. Mains voltage conversion

The instrument can be converted into two mains voltage ranges 100—130 V and 200—260 V. The frequency range is 50 to 400 Hz. At delivery the instrument is set to the 200 to 260 V range.
When changing to the 100 to 130 V range the connections of the mains transformer should be changed as shown in figure IV-1, and the label "230 V" covered with the "115 V" label supplied.



Figure IV-1. Mains transformer connections

2. Earthing

The local safety regulations prescribe how the instrument should be earthed. Two ways are possible:

1. Via the protective earth terminal at the rear panel.
2. Via the three core mains cable plugged into an outlet with protective earth contact.

NOTE: Use only **one** of these alternatives to avoid hum!

3. Fuses

A thermal fuse on the mains transformer and a 1.6 A fuse, fast action, on unit U1 are protecting the power supply. Figures VI-1 to VI-5 on pages 42 and 43.

4. Optional accessories

Refer to installation instruction given in manual for each type number.

V. CONTROLS, INDICATORS AND CONNECTORS

Figures VI-1 to VI-5 on pages 42 and 43

1 DISPLAY TIME

Sets display time between 0.2 and 5 s.
Infinite display time when knob is pulled.
With switch set to position STAND BY the counter is turned off except the oven oscillator.
WARNING: Primary voltage of power supply is on!

2 GATE

Lamp indicating that the main gate is open and that counting takes place. With DISPLAY TIME knob set to position STAND BY the GATE lamp is on permanently indicating that the oven oscillator is on.

3 SENSITIVITY

Sensitivity control for input A. When pushed, this control provides continuous setting of the sensitivity between approximately 4 V and 200 mV. With knob pulled the sensitivity can be set between 220 mV and 10 mV.

4 ⊓

When measuring signals at input A with duty factor > 0.75 this push-button must be depressed to obtain reliable triggering.

5 5—250 MHz, PM 6613
50—520 MHz, PM 6614
50 MHz—1 GHz, PM 6615

Turns on channel B when depressed.
Not present in PM 6611.

6 ⊔

When measuring signals at input A with duty factor < 0.25 this push-button must be depressed to obtain reliable triggering.

7 ~

When measuring signals at input A with duty factor 0.25—0.75 this push-button must be depressed to obtain reliable triggering.

7 10 CHECK

When depressed the instrument is set to self check mode.

8 B

Input B. Signal input for FREQUENCY or RATIO measurement. Frequency range:

PM 6613,	5 MHz	to	250 MHz
PM 6614,	50 MHz	to	520 MHz
PM 6615,	50 MHz	to	1 GHz

Not present in PM 6611.

9 A

Input A. Signal input for COUNT, FREQUENCY, PERIOD and RATIO measurement. Frequency range 10 Hz to 80 MHz.

10 < 100 kHz ~

Low-pass filter. When measuring noisy signals at input A with duty factor ≈ 0.5 and frequency < 100 kHz triggering is improved by depressing this push-button.

⑪ **Function selector**

COUNT A — Sets counter to add the pulses at input A in the time interval between depressing and releasing the START/STOP push-button.

FREQUENCY — Sets counter to measure frequency.
MHz and kHz are measuring units related to the display read-out.
100 Hz, 10 Hz, 1 Hz and 0.1 Hz is the resolution of the least significant digit.

PERIOD A — Sets counter to measure period at input A.
μs is the measuring unit related to the display read out. $n=1$, $n=10^2$ and $n=10^4$ indicates the number of periods being measured.

RATIO A/C and B/C — Sets counter to measure ratio between signals applied to inputs A and C or B and C.
$n=10^2$ and $n=10^4$ indicate the number of decimals displayed.

⑫ **MEMORY START/STOP** — In released position the measurement information is stored until next measurement cycle is completed.
Depressed button makes display follow decade counters continuously.
In COUNT A mode, start/stop operation.

⑬ **RESET** — Resets decade counter and display to zero.

Rear panel

⑭ Mains input.

⑮ **INT.BATT.OFF MAINS/EXT.BATT.** — Turns the internal battery off.
The mains or the external battery is the power source for the instrument.
Internal battery is charged when mains cable is connected.

⑮ **INT.BATT.ON** — Sets power supply to be fed from the internal battery. Turns the mains or the external battery off.

⑯ **INPUT C** — Input C. Signal input for external time base signal 1 kHz to 10 MHz and RATIO measurement.

⑰ **10 MHz OUT** — Output for the internal oscillator signal.

⑱ **BCD** — Input connector for BCD unit.

⑲ ⏚ — Chassis ground.

⑳ − — Minus-pole connection for external battery.

㉑ + — Plus-pole connection for external battery.

㉒ **INT.STD EXT.STD IN VIA C** — Sets counter to operate with either internal or external oscillator (earlier versions have an internal jumper).

㉓ — Connector for D/A converter and BCD unit.

VI. OPERATION

Figures VI-1 to VI-5 on pages 42 and 43

General Information

1. Switch on power

1.1. Mains

Before connecting the counter to the mains check that the mains transformer is wired for the local mains voltage. Refer to chapter IV, INSTALLATION.
Set switch MAINS EXT.BATT./INT.BATT.ON to position MAINS EXT.BATT. ⓯.
Connect mains cable to the counter at ⓮.
Turn DISPLAY TIME control ❶ to ON. Check that GATE lamp ❷ and display are on, indicating that power is on.

1.2. External battery

Set switch MAINS EXT. BATTERY/INT. BATT. ON ⓯ to position MAINS EXT.BATTERY.
Connect the cables from the external battery to sockets EXT.BATT. 12—24 V "+" ㉑ and "—" ⑳.
Check that GATE lamp ❷ and display are on, indicating that power is on.

1.3. Internal battery PM 9673

Set switch MAINS EXT. BATTERY/INT. BATTERY ON ⓯ to position INT.BATTERY ON.
Check that GATE lamp ❷ and display lights indicating that power is on. Blinking display indicates low voltages. Refer to manual PM 9673 for charging instructions.

2. Warm up time

The warm up time from the moment of mains connection is less than 7 minutes to an oscillator error of less than 10^{-7} for instrument equipped with the oven-enclosed oscillators PM 9679 or PM 9690. Instruments equipped with the oscillators PM 9677 or PM 9678 (TCXO) are ready for use at the moment of mains connection. Normally the instrument is switched on from the STAND BY ❶ position. If so, no warm up time is needed, irrespective of which oscillator is employed.

3. External frequency standards

House standards or other frequency standards can be used instead of the internal 10 MHz oscillator. If a time resolution of 100 ns is required, 10 MHz must be used.
When using 1 MHz instead of 10 MHz the decimal point must be shifted one step to the left to interpret the display correctly. To set the counter to external standard the internal jumper SK 131 ㉒, or SK 22 ㉒ at the rear panel, must be set to position EXT.STD.

Measurements

Figures VI-1 to VI-5 on pages 42 and 43

4. CHECK

1. Depress the two CHECK push-buttons ❼ ❿.
2. Set DISPLAY TIME ❶ to mid-position
3. Rotate switch ⓫ and read display value as follows:

Function	Read (±1 digit)
FREQ 100 Hz	10.0000
FREQ 10 Hz	10.00000
FREQ 1 Hz	10000.000
FREQ 0.1 Hz	10000.0000
PERIOD n = 1	00000000.1
PERIOD n = 10^2	0.100
PERIOD n = 10^4	0.10000

4. Set switch ⓫ to position COUNT A.
5. Depress START/STOP push-button ⓬ : the counter will start totalizing the input pulses and the display will follow the counting continuously until push-button START/STOP ⓬ is released again.

5. FREQ. A

1. Set DISPLAY TIME ❶ to mid position.
2. Set function selector ⓫ to any of the four frequency positions that corresponds to the desired resolution of the measurement.
3. Connect the signal to be measured to input A ❾.
4. Match the input of the counter to the frequency and dutyfactor of the signal to be measured by depressing any of push-buttons ❹ ❻ ❼ ❿.
5. Adjust SENSITIVITY control ❸ for stable display read-out.

6. FREQ. B (not present in PM 6611)

1. Set DISPLAY TIME ❶ to mid position.
2. Turn on channel B by depressing the push-button ❺.
3. Set function selector ⓫ to any of the four frequency positions that corresponds to the desired resolution of the measurement.
4. Connect the signal to be measured to input B ❽.

7. PERIOD A

1. Set function switch ⓫ to any of the three PERIOD A positions depending on the desired number of periods to be measured.
2. Match the input of the counter to the frequency and dutyfactor of the signal to be measured by depressing any of the push-buttons ❹ ❻ ❼ ❿.

8. RATIO A/C*

1. Set function switch ⓫ to any of the two RATIO positions depending on the desired number of decimals of the display read-out.
2. Set DISPLAY TIME ❶ to mid position.
3. Connect the signal with the highest frequency to input A ❾.
4. Match the input of the counter to the frequency and duty factor of the signal to be measured by depressing any of the push-buttons ❹ ❻ ❼ ❿.
5. Connect the signal with the lowest frequency to input C ⓰.
6. Adjust SENSITIVITY control ❸ for stable display read-out.

9. RATIO B/C* (not present in PM 6611)

1. Set function switch ⓫ to any of the two RATIO positions depending on the desired number of decimals of the display read-out.
2. Set DISPLAY TIME ❶ to mid-position.
3. Connect the signal with the highest frequency to input B ❽.
4. Turn on channel B by depressing the push-button ❺.
5. Connect the signal with the lowest frequency to input C ⓰.

10. TOTALIZE (COUNT A)

1. Set function switch ⓫ to position COUNT A.
2. Connect the signal to be measured to input A ❾.
3. Match the input of the counter to the frequency and duty factor of the signal to be measured by depressing any of the push-buttons ❹ ❻ ❼ ❿.
4. Set DISPLAY TIME ❶ to mid position.
5. Depress START/STOP push-button ⓬.
6. When depressing the START/STOP push-button ⓬ the counter will start totalizing the input pulses until push-button START/STOP ⓬ is released again. The display will show the number of pulses counted in the time interval between depressing and releasing the START/STOP push-button ⓬.

* **NOTE**

Multiplier factors 10^5, 10^6, 10^7 and 10^8 are possible in the frequency mode by using input C as the external time base reference input. (set the internal jumper switch ㉒ or switch ㉒ at the rear panel to position EXT.STD.)
The decimal point is then incorrectly positioned.

Gebrauchsanleitung

I. EINLEITUNG

ALLGEMEINES

Die Geräte der Serie PM 6610 haben einen Frequenzbereich von 10 Hz bis 80 MHz, 250 MHz, 520 MHz und 1 GHz (PM 6611 bzw. PM 6613, PM 6614 und PM 6615).
Die VHF- und UHF-Zähler PM 6613, PM 6614 und PM 6615 verfügen über zwei verschiedene Signaleingänge für HF- und NF-Signale. Sämtliche Modelle können Frequenz, Periodendauer und Frequenzverhältnis messen und Ereignisse zählen.
Wahlweises Zubehör wie vier verschiedene Oszillatoren, eine Batterie-Einheit, ein BCD-Ausgang und ein D/A-Ausgang erweitern noch den Anwendungsbereich.

II. TECHNISCHE DATEN

In Zahlen mit Toleranzangabe ausgedrückte Eigenschaften werden vom Hersteller garantiert. Zahlen ohne Toleranzangabe sind nur zur Information und geben die Eigenschaften eines Durchschnittsgeräts an. Sämtliche Werte gelten nur bei Nenn-Netzspannung.

A. MESSARTEN

Frequenz

Bereich	10 Hz—80 MHz, PM 6611 10 Hz—250 MHz, PM 6613 10 Hz—520 MHz, PM 6614 10 Hz—1000 MHz, PM 6615
Meßzeiten	10 ms, 100 ms, 1 s und 10 s, Eingang A. Bei Verwendung von Eingang B wird die Meßzeit mit dem Vorteilerfaktor multipliziert
Auflösung	100 Hz, 10 Hz, 1 Hz und 0,1 Hz
Fehler	± 1 Ziffer ± Zeitbasisfehler

Periodenmessung A

Bereich	100 ns—100 s
Zählfrequenz	10 MHz
Zeitauflösung	100 ns
Fehler	± 1 Ziffer ± Triggerfehler* ± Zeitbasisfehler

---

* Der Triggerfehler beträgt $\leq 3 \times 10^{-3}$ bei Signalen mit einem Signal/Rausch-Verhältnis von $\geq$ 40 dB.

Periodenmittelwertmessung A

Bereich	Sinussignale: 10 Hz—10 MHz Impulse: 1 Hz—10 MHz
Zählfrequenz	10 MHz
Mittelwertbildung über N-Perioden	$N = 10^2$ und 10^4
Zeitauflösung	$\frac{100\ ns}{N}$
Fehler	± 1 Ziffer ± Triggerfehler/N* ± Zeitbasisfehler

Ereigniszählung A

Bereich	1 bis 999999999
Betriebsart	Summiert Impulse während manuell gesteuertem Start-Stopp-Intervall
Min. Abstand zweier Impulse	12 ns

Frequenzverhältnis A/C oder B/C

Bereich	f_A:	10 Hz—80 MHz (sämtl. Modelle)
	f_B:	5— 250 MHz, PM 6613 50— 520 MHz, PM 6614 50—1.000 MHz, PM 6615
	f_C:	1 kHz—10 MHz (sämtl. Modelle)
Vervielfachungsfaktor		$N = 10^2$ und 10^4 mit automatischer Einstellung des Dezimalpunktes
Fehler		± 1 Ziffer ± Triggerfehler* von f_C/N
Eigenkontrolle		10 MHz, intern auf Kanal A Es kann jede Meßfunktion gewählt werden

Hilfsfunktionen

Rückstellung	Durch Drücken der Taste RESET wird der Zähler rückgestellt. Bei Lösen der Taste RESET beginnt eine neue Messung.
Start/Stopp	In Stellung COUNT A wird die Meßzeit manuell mit der Drucktaste START/STOP geregelt. Der Speicher wird automatisch abgeschaltet.
Anzeigedauer	Stufenlos von 0,2—5 s regelbar, bei herausgezogenem Drehknopf DISPLAY TIME unbegrenzt.
Oszillatorheizung	Kombiniert mit dem Drehknopf DISPLAY TIME. In der Stellung STAND BY wird nur der Oszillator geheizt.
Speicher	Schaltbar durch Wähltaste MEMORY

B. EINGANGSCHARAKTERISTIKA

Eingang A

Bereich	10 Hz—80 MHz Gesamtbereich, 10 Hz—100 kHz wenn durch die Drucktaste »<100 kHz« ein Tiefpassfilter verwendet wird.
Empfindlichkeit	Sinussignale: 10 mV_{eff}, 6 dB niedriger bei 10 Hz Impulse: 30 mV_{ss} bei einer Impulsbreite von ≦ 6 ns und einer Anstiegzeit von ≦ 1 ms
Impedanz	1 MΩ//25 pF
Kopplung	AC
Dämpfung	Stufenlos einstellbar zwischen 1×—400×
Triggerung (Pegel)	Für Signale mit einem Tastverhältnis zwischen 25% und 75% : ∼ (Nulldurchgang) Für Signale mit einem Tastverhältnis < 25% : ⎍ (Impulsvorderflanke) Für Signale mit einem Tastverhältnis > 75% : ⎍ (Impulsvorderflanke)
Überlastungsschutz	
Dämpfung ×1	max. 250 V oder 230 V_{eff} ≦ 440 Hz > 440 Hz: fallend auf 12 V_{eff} bei > 1 MHz
Dämpfung ×20	max. 250 V oder 230 V_{eff}

* Der Triggerfehler beträgt ≤ 3×10^{-3} bei Signalen mit einem Signal/Rausch-Verhältnis von ≥ 40 dB.

Eingang B (nicht vorhanden an PM 6611)

Frequenzbereich	5— 250 MHz, PM 6613 50— 520 MHz, PM 6614 50—1000 MHz, PM 6615
Dynamischer Eingangsspannungsbereich	10 mV_{eff}*—12 V_{eff} (—27 dBm*—+35 dBm)
Impedanz	50 Ω
VSWR	< 2
Kopplung	AC
Dämpfung	durch automatischen PIN-Dioden-Dämpfer, max. 62 dB
Vorteilungsfaktor	4 (PM 6613) 8 (PM 6614) 16 (PM 6615)
Überlastungsschutz	12 V_{eff}
Unempfindlichkeit für Amplitudenmodulation	98% bei ≤ 5 kHz Modulationsfrequenzen 30% bei ≥ 1 MHz Modulationsfrequenzen } sämtliche Modelle

Eingang C (auf der Rückseite)

Bereich	1 kHz—10 MHz
Empfindlichkeit	500 mV_{eff}
Kopplung	Wechselstrom
Impedanz	≈ 10 kΩ
Überlastungsschutz	50 V_{eff}
Externer Oszillator	Über Eingang C.

C. AUSGANGSCHARAKTERISTIKA

10 MHz OUT

Ausgangsfrequenz	Frequenz des internen Oszillators (10 MHz)
Signalpegel	≈ 1 V_{eff} (Leerlauf)
Ausgangsimpedanz	Ca. 200 Ω (kurzschlußsicher)
Kopplung	AC
Anzeige	9 Ziffern 7 Segment-Gasentladungs-Anzeige mit automatischem Dezimalpunkt.

Tor (GATE) — Zeigt an, daß das Haupttor offen ist und eine Zählung stattfindet. In der Stellung STAND BY zeigt die Torlampe an, daß das Gerät am Netz oder an der Batteriespannung liegt.

D. ALLGEMEINE CHARAKTERISTIKA

Oszillator — Siehe unter Abschnitt »Zubehör«, Punkt 2.1. und in der Gebrauchsanleitung.

Stromversorgung

Netz	100—130 V oder 200—260 V bei 50—400 Hz, 15—25 VA
Äußere Batterie	+11.8—+28 V, max 1 A—0.5 A bei resp. 12 V—24 V. 100 mA für den Thermostaten (STAND BY)
Anschlüsse	4 mm Bananenstecker
Wahlweise eingebaute Batterie	PM 9673

---

* Die Empfindlichkeit des Zählers PM 6615 kann oberhalb 960 MHz bis auf —24 dBm (14 mV_{eff}) bei 1 GHz abfallen.

Umgebungsbedingungen

Temperaturbereich	
Lagerung	—40° C bis +70° C —40° C bis +50° C (mit eingebauter Batterie PM 9673)
Betrieb	0° C bis +50° C 0° C bis +40° C (mit eingebauter Batterie PM 9673)
Netzstörung	unter CISPR
Höhe	Lagerung: 15.000 m Betrieb: 5.000 m
Feuchtigkeit	Max. 90 % rel. (Taupunkt 26°)
Stoßsicherheit	Genügt den Anforderungen der IEC-Empfehlungen 68 Eb
Erschütterungssicherheit	Genügt den Anforderungen der IEC-Empfehlungen 68 F

Abmessungen

Breite	210 mm
Höhe	89 mm
Tiefe	325 mm

Gewicht Ca. 2,8 kg

III. ZUBEHÖR

1. Mitgeliefertes Standardzubehör

1 Netzkabel
1 Bedienungsanleitung
1 flinke Sicherung, 1,6 A
1 Schild »115 V«

2. Zusätzlich lieferbares Zubehör

2.1. Oszillatoren
PM 9677 Standardoszillator
PM 9678 TCXO
PM 9679 Ofen-Oszillator
PM 9690 Hochstabiler Oszillator

2.2. Ausgangseinheiten
PM 9674 BCD-Ausgangseinheit
PM 9675 D/A-Ausgang

2.3. Tastköpfe
PM 9351 Passiver Tastkopf 10 MΩ/11 pF, 220 MHz, Dämpfung 10×
PM 9353 FET-Tastkopf 1 MΩ/3,5 F, 220 MHz
PM 9584 Widerstandmischglied
PM 9346 Stromversorgung f. aktiven Tastkopf

2.4. Koaxialkabel
PM 9074 50 Ω, BNC—BNC, Länge 1 m
PM 9588 Satz aus 50-Ω-Kabeln, BNC—BNC:
5 Kabel, Länge 20,7 cm
4 Kabel, Länge 40,5 cm
3 Kabel, Länge 60,3 cm
3 Kabel, Länge 198,6 cm

2.5. Netzkabel
PM 9011 abnehmbares 3-Leiter-Netzkabel

2.6. 19″ Zusatz für Montage auf Ständer
PM 9669/01 für einen Zähler
PM 9669/02 für zwei Zähler

2.7. Batterieeinheit
PM 9673 eingebaute Batterieeinheit

2.8. Tragtasche
PM 9672 Gerätetragttasche

IV. INSTALLATION

1. Netzanschluß

Die Geräte können an zwei Netzspannungsbereiche, 100—130 V und 200—260 V, angeschlossen werden. Der Frequenzbereich liegt zwischen 50 und 400 Hz. Bei Lieferung sind die Geräte auf den Spannungsbereich von 200—260 V eingestellt.

Soll das Gerät an 100—130 V angeschlossen werden, so sind die Anschlüsse des Netztrafos entspr. Abb. IV-1 zu vertauschen und das Schild »115 V« über das Schild »230 V« zu schieben.



Abb. IV-1 Netztrafo-Anschlüsse

2. Erdung

Die Geräte sind den örtlichen Sicherheitsvorschriften entsprechend zu erden. Dies kann erfolgen über:

1. die Schutzerdungsklemme auf der Geräterückseite
2. das 3-Leiter-Netzkabel, dessen Netzstecker an eine Schukosteckdose anzuschließen ist.

ZUR BEACHTUNG: Doppelerdung ist zu vermeiden, damit keine Brummstörungen auftreten!

3. Sicherungen

Der Stromversorgungsteil ist durch eine thermische Sicherung am Netztrafo und eine flinke 1,6-A-Sicherung an der Einheit U1 abgesichert. Die abbildungen VI-1 zu VI-5 an den Seiten 42 und 43.

4. Wahlweises Zubehör

Näheres ist den Anweisungen in der Bedienungsanleitung des jeweiligen Zubehörs zu entnehmen.

V. BEDIENUNGSORGANE UND ANSCHLÜSSE

Die Abbildungen VI-1 zu VI-5 an den Seiten 42 und 43

1 DISPLAY TIME

Einstellung der Anzeigedauer auf 0,2—5 s.
Unbegrenzte Anzeigedauer bei herausgezogenem Knopf. Steht der Schalter auf STAND BY, so ist der Zähler mit Ausnahme des Oszillator abgeschaltet. ACHTUNG! Gerät liegt an Primärspannung des Stromversorgungsteils!

2 GATE

Leuchtet auf, wenn das Haupttor offen ist und eine Zählung stattfindet. Steht der Schalter DISPLAY TIME auf STAND BY, so zeigt diese Lampe an, daß der Oszillator ständig geheizt wird.

3 SENSITIVITY

Empfindlichkeitswähler für Eingang A. Bei gedrücktem Schaltknopf kann die Empfindlichkeit stufenlos von ca. 4 V—200 mV geregelt werden, bei herausgezogenem Schaltknopf von 220 mV—10 mV.

4 ⊓⊔

Bei Messen von Signalen mit einem Tastverhältnis von > 0,75 am Eingang A ist diese Taste zu drücken, um eine verläßliche Triggerung zu gewährleisten.

5 5—250 MHz, PM 6613
50—520 MHz, PM 6614
50 MHz—1 GHz, PM 6615

Schaltet bei Drücken den Kanal B ein.
Nicht vorhanden an PM 6611.

6 ⊔⊓

Bei Messen von Signalen mit einem Tastverhältnis von < 0,25 am Eingang A ist diese Taste zu drücken, um eine verläßliche Triggerung zu gewährleisten.

7 ~

Bei Messen von Signalen mit einem Tastverhältnis von 0,25—0,75 am Eingang A ist diese Taste zu drücken, um eine verläßliche Triggerung zu gewährleisten.

7 10 CHECK

Einstellung auf Eigenkontrolle

8 B

Eingang B. Signaleingang für Messungen von Frequenz oder Frequenzverhältnis. Frequenzbereiche:

PM 6613	5 MHz—250 MHz
PM 6614	50 MHz—520 MHz
PM 6615	50 MHz— 1 GHz

Nicht vorhanden an PM 6611.

9 A

Eingang A. Signaleingang für Ereigniszählung, Messungen von Frequenz, Frequenzverhältnis und Periodendauer. Frequenzbereich 10 Hz—80 MHz.

10 < 100 kHz ~

Tiefpassfilter. Bei Messen von rauschgestörten Signalen mit einem Tastverhältnis von ≈0,5 und einer Frequenz von < 100 kHz am Eingang A wird die Triggerung durch Drücken dieser Taste verbessert.

⓫ Funktionswählschalter

COUNT A — In dieser Stellung des Wählschalters summiert das Gerät die Impulse am Eingang A, solange die Taste START/STOP gedrückt ist.

FREQUENCY — Einstellung auf Frequenzmessung.
Die Meßeinheit der angezeigten Werte ist MHz oder kHz.
Die Auflösung der niedrigsten Stelle ist 100 Hz, 10 Hz, 1 Hz und 0,1 Hz.

PERIOD A — Einstellung auf Messung der Periodendauer am Eingang A.
Die Meßeinheit der Anzeigewerte ist 1 μs.
$n=1$, $n=10^2$ und $n=10^4$ zeigen die Zahl der zu messenden Perioden an.

RATIO A/C und B/C — Einstellung auf Messung des Frequenzverhältnisses zwischen Signalen am Eingang A und C bzw. B und C.
$n=10^2$ und $n=10^4$ sind Vervielfachungsfaktoren.

⓬ MEMORY START/STOP — Bei nicht gedrückter Taste wird die Meßanzeige bis Ende des nächsten Meßzyklus gespeichert.
Bei gedrückter Taste folgt die Anzeige laufend den Dekadenzählern.
Start/Stop-Betrieb, wenn der Funktionswählschalter auf COUNT A steht.
Der Speicher ist dann ausgeschaltet.

⓭ RESET — Rückstellung von Dekadenzähler und Anzeige auf Null.

Rückseite

⓮ — Netzanschluss

⓯ INT.BATT.OFF MAINS/EXT.BATT. — Abschaltung der eingebauten Batterie.
Das Gerät ist an das Netz oder eine äußere Batterie angeschlossen. Bei Netzanschluß wird die eingebaute Batterie aufgeladen.

⓯ INT.BATT.ON — Stromversorgung des Geräts durch die eingebaute Batterie. Netz oder äußere Batterie sind weggeschaltet.

⓰ INPUT C — Eingang C. Für externe Zeitbasissignale von 1 kHz—10MHz und zur Messung von Frequenzverhältnissen.

⓱ 10 MHz OUT — Ausgang für Signale des eingebauten Oszillators.

⓲ BCD — BCD-Ausgang.

⓳ ⏚ — Gehäuseerdung.

⓴ — — Anschluß für Minuspol der äußeren Batterie.

㉑ + — Anschluß für Pluspol der äußeren Batterie.

㉒ INT.STD EXT.STD IN VIA C — Umschaltung auf internen oder externen Oszillator.
(ältere Geräte haben interne Schaltbrücke)

㉓ — Anschluss für D/A-Ausgang und BCD-Ausgang.

VI. BETRIEB

Die Abbildungen VI-1 zu VI-5 an den Seiten 42 und 43

Allgemeines

1. Inbetriebnahme

1.1. Netz

Vor Anschluß des Geräts an das Netz ist zu überprüfen, ob der Netztrafo der Netzspannung entsprechend geschaltet ist. Vgl. Abschnitt IV, INSTALLATION. Schalter MAINS EXT.BATT./INT.BATT.ON in Stellung MAINS EXT.BATT. bringen. ⓯.
Netzkabel einstecken ⓮.
Schalter DISPLAY TIME ❶ auf ON stellen. Überprüfen, ob die Lampe GATE ❷ und die Zifferanzeige leuchten und damit anzeigen, daß das Gerät eingeschaltet ist.

1.2. Äußere Batterie

Schalter MAINS EXT.BATT./INT.BATT.ON ⓯ in Stellung MAINS EXT.BATT. bringen.
Batteriekabel in Buchsen EXT.BAT. 12—24 V »+« ㉑ und »—« ⓴ einstecken.
Überprüfen, ob die Lampe GATE ❷ und die Zifferanzeige leuchten und anzeigen, daß das Gerät eingeschaltet ist.

1.3. Eingebaute Batterie PM 9673

Schalter MAINS EXT.BATT./INT.BATT.ON ⓯ in Stellung INT.BATT.ON bringen.
Überprüfen, ob Lampe GATE ❷ und die Zifferanzeige leuchten und anzeigen, daß das Gerät eingeschaltet ist. Bei blinkender Ziffernanzeige is die Batteriespannung zu niedrig. Die Bedienungsanleitung zur Batterie PM 9673 beschreibt die Aufladung.

2. Aufwärmzeit

Sieben Minuten nach Netzanschluß sind Geräte mit den geheizten Oszillatoren PM 9679 oder PM 9690 so weit aufgewärmt, daß der Oszillatorfehler weniger als 10^{-7} beträgt. Geräte mit den Oszillatoren PM 9677 oder PM 9678 (TCXO) sind sofort nach Netzanschluß betriebsbereit. Normalerweise werden die Geräte aus der Stellung STAND BY ❶ eingeschaltet. In diesem Fall ist keine Aufwärmzeit erforderlich, gleichgültig welcher Oszillator verwendet wird.

3. Externe Frequenz-Standards

Anstelle der Frequenz 10 MHz des eingebauten Oszillators können auch andere Frequenz-Normale verwendet werden. Falls eine Zeitauflösung von 100 ns erwünscht ist müssen 10 MHz verwendet werden.
Bei einer Frequenz von 1 MHz anstelle von 10 MHz ist der Dezimalpunkt zur Anzeigenkorrektur um eine Stelle nach links zu verschieben. Um das Gerät auf externe Normalfrequenz einzustellen, ist der obere Deckel abzunehmen und die Schaltbrücke SK 131 ㉒ in die Stellung EXT zu bringen.
Bei neueren Geräten ist dieser Schalter direkt an der Rückseite zugänglich.

Messungen

Die Abbildungen VI-1 zu VI-5 an den Seiten 42 und 43

4. EIGENKONTROLLE

1. Die beiden Tasten CHECK ❼ ❿ drücken.
2. Schalter DISPLAY TIME ❶ in mittlere Stellung bringen.
3. Wählschalter ⓫ drehen und folgende Anzeigewerte ablesen:

Funktion	Anzeige (± 1 Ziffer)
FREQ 100 Hz	10.0000
FREQ 10 Hz	10.00000
FREQ 1 Hz	10000.000
FREQ 0,1 Hz	10000.0000
PERIOD n = 1	00000000.1
PERIOD n = 10^2	0.100
PERIOD n = 10^4	0.10000

4. Wählschalter ⓫ in Stellung COUNT A bringen.
5. Taste START/STOP ⓬ drücken: Das Gerät beginnt nun die Eingangsimpulse zu summieren und die Anzeige folgt der Zählung solange bis die Taste START/STOP ⓬ wieder gelöst wird.

5. FREQUENZ A

1. Schalter DISPLAY TIME ❶ in mittlere Stellung bringen.
2. Funktionswähler ⓫ auf die Frequenz einstellen, die der gewünschten Meßauflösung entspricht.
3. Das zu messende Signal an Eingang A ❾ legen.
4. Eingang des Geräts durch Drücken einer der Tasten ❹ ❻ ❼ ❿ an die Frequenz und das Tastverhältnis des zu messenden Signals anpassen.
5. Anzeige durch Nachregeln mit SENSITIVITY ❸ stabilisieren.

6. FREQUENZ B (nicht vorhanden an PM 6611)

1. DISPLAY TIME ❶ in mittlere Stellung bringen.
2. Kanal B einschalten durch Drücken der Taste ❺.
3. Funktionswähler ⓫ auf die Frequenz einstellen, die der gewünschten Meßauflösung entspricht.
4. Das zu messende Signal an den Eingang B ❽ legen.

7. PERIODENDAUER A

1. Funktionswähler ⓫ je nach gewünschter Anzahl der zu messenden Perioden in eine der drei Stellungen PERIOD A bringen.
2. Eingang des Geräts durch Drücken einer der Tasten ❹ ❻ ❼ ❿ an die Frequenz und das Tastverhältnis des zu messenden Signals anpassen.

8. FREQUENZVERHÄLTNIS A/C*

1. Funktionswähler ⓫ je nach gewünschter Vervielfachung in eine der beiden Stellungen RATIO bringen.
2. DISPLAY TIME ❶ in mittlere Stellung bringen.
3. Signal mit der höheren Frequenz an den Eingang A ❾ legen.
4. Eingang des Geräts durch Drücken einer der Tasten ❹ ❻ ❼ ❿ an die Frequenz und das Tastverhältnis des zu messenden Signals anpassen.
5. Signal mit der niedrigeren Frequenz an den Eingang C ⓰ legen.
6. Anzeige durch Nachregeln mit SENSITIVITY ❸ stabilisieren.

9. FREQUENZVERHÄLTNIS B/C*

(nicht vorhanden an PM 6611)

1. Funktionswähler ⓫ je nach gewünchter Anzahl von Dezimalen auf der Anzeige in eine der beiden Stellungen RATIO bringen.
2. DISPLAY TIME ❶ in mittlere Stellung bringen.
3. Signal mit der höheren Frequenz an den Eingang B ❽ legen.
4. Kanal B durch Drücken der Taste ❺ einschalten.
5. Signal mit der niedrigeren Frequenz an den Eingang C ⓰ legen.

10. IMPULSZÄHLUNG

1. Funktionswähler ⓫ auf COUNT A stellen.
2. Das zu messende Signal an den Eingang A ❾ legen.
3. Eingang des Geräts durch Drücken einer der Tasten ❹ ❻ ❼ ❿ an die Frequenz und das Tastverhältnis des zu messenden Signals anpassen.
4. DISPLAY TIME ❶ in mittlere Stellung bringen.
5. Taste START/STOP ⓬ drücken.
6. Nach Drücken der Taste START/STOP ⓬ beginnt das Gerät die Impulse des Eingangssignals zu zählen, bis die Taste wieder gelöst wird. Die Anzeige entspricht dann der Anzahl der Impulse, die vom Drücken bis zum Wiederlösen der Taste START/STOP ⓬ gezählt wurden.

*** ZUR BEACHTUNG:**

Bei Frequenzmessung sind die Vervielfachungsfaktoren 10^5, 10^6, 10^7 und 10^8 möglich, wenn der Eingang C als Eingang für die externe Zeitbasis benützt wird. (Schaltbrücke im Geräteinnern ㉒ auf EXT. legen oder Schalter ㉒ auf der Rückseite auf EXT.STD legen.)
Die Lage des Dezimalpunkts ist in diesem Fall nicht korrekt.

Notice d'emploi

I. INTRODUCTION — GENERALITES

Les compteurs des séries PM 6610, respectivement le PM 6611, PM 6613, PM 6614 et PM 6615, ont des gammes de fréquences de 10 Hz à 80 MHz, 250 MHz, 520 MHz et 1 GHz.
Les compteurs VHF et UHF, PM 6613, PM 6614 et PM 6615, disposent de deux différentes entrées de signal pour signaux HF et BF.
Tous les modèles peuvent mesurer la fréquence, la période, le rapport de fréquence et sont dotés d'un mode comptage.
Les accessoires optionnels, quatre différents oscillateurs, une unité de batterie rechargeable, une unité de sortie BCD et un convertisseur digital/analogique, élargissent encore le champ d'application.

II. CARACTERISTIQUES TECHNIQUES

Les propriétés exprimées en valeurs numériques avec indication de tolérance sont garanties. Les valeurs numériques sans tolérances ne sont mentionnées qu'à titre indicatif et correspondent aux caractéristiques d'un appareil moyen. Les valeurs numériques correspondent aux tensions secteur nominales.

A. MESURES

Fréquence

Gamme	10 Hz—80 MHz, PM 6611 10 Hz—250 MHz, PM 6613 10 Hz—520 MHz, PM 6614 10 Hz—1000 MHz, PM 6615
Temps de porte	10 ms, 100 ms, 1 s et 10 s, INPUT A. La base de temps est multipliée par un facteur de prédétermination en utilisant l'entrée B
Résolution	100 Hz, 10 Hz, 1 Hz et 0,1 Hz
Précision	± 1 comptage ± erreur base de temps

Période simple A

Gamme	100 ns—100 s
Fréquence comptée	10 MHz
Résolution	100 ns
Précision	± 1 digit ± erreur de déclenchement* ± erreur temps de base

* L'erreur de déclenchement est de ≤ 0,3 % pour les signaux dont le rapport signal/bruit est de ≥ 40 dB.

Période moyenne A

Gamme	onde sinusoidale: 10 Hz—10 MHz impulsions: 1 Hz—10 MHz
Nombre de périodes	$N = 10^2$ et 10^4
Résolution	$\frac{100\ ns}{N}$
Précision	± 1 digit ± erreur de déclenchement/N* ± erreur temps de base

Comptage A

Gamme	1 à 999999999
Mode	Accumule les impulsions durant l'intervalle de temps start-stop manuel.
Résolution de paire d'impulsions	12 ns

Rapport de fréquence A/C ou B/C

Gamme	f_A : 10 Hz—80 MHz (tous les modèles) f_B : 5— 250 MHz, PM 6613 50— 520 MHz, PM 6614 50—1000 MHz, PM 6615 f_C : 1 kHz—10 MHz (tous les modèles)
Multiplicateur	$N = 10^2$ ou 10^4 avec positionnement automatique de la virgule
Précision	± 1 digit ± erreur de déclenchement* de f_C/N
Contrôle	10 MHz appliqués internement au canal A. Toute fonction de mesure peut être sélectionnée

Fonctions auxiliaires

Remise à zéro	En appuyant sur le bouton « RESET » le compteur est remis à zéro. En relachant le bouton « RESET » une nouvelle mesure commence.
Mise en marche/Arrêt	En fonction « COUNT A » le temps de porte est contrôlé manuellement par le bouton « START/STOP ». La mémoire est automatiquement supprimée.
Temps d'affichage	Variable en continu de 0,2 à 5 s, infini lorsque le bouton « DISPLAY TIME » est tiré.
Disponibilité	Le commutateur est combiné à la commande du temps d'affichage. La position « STAND BY » maintient sous tension l'enceinte thermostatée.
Mémoire	Commutable par le bouton « MEMORY »

B. CARACTÉRISTIQUES D'ENTRÉE

Entrée A

Gamme	10 Hz à 80 MHz gamme globale, 10 Hz à 100 kHz lorsque le filtre passe-bas est sélectionné par le bouton « < 100 kHz »
Atténuation	Continuement variable de X1—X400
Sensibilité	Onde sinusoidale: 10 mV_{eff}, moin 6 dB à 10 Hz Impulsions: $30mV_{pp}$ pour une largeur d'impulsion ≥ 6ns et un temps de montée ≤ 1ms
Impédance	1 MΩ//25 pF
Couplage	AC
Mode de déclenchement (niveau)	~ : pour des signaux ayant un facteur de forme compris entre > 25% et < 75% (passage par zéro) ⊓ : pour des signaux ayant un facteur de forme inférieur à > 25% (sur flanc avant) ⊓ : pour des signaux ayant un facteur de form supérieur à < 75% (sur flanc avant)

* L'erreur de déclenchement est de $\leq 3 \times 10^{-3}$ pour les signaux dont le rapport signal/bruit est de ≥ 40 dB.

Protection de surcharge			
Affaiblissement ×1	maxi 250 V DC ou 230 V_{eff} ≦ 440 Hz > 440 Hz: tombant à 12 V_{eff} à > 1 MHz		
Affaiblissement ×20	maxi 250 V DC ou 230 V_{eff}		
Entrée B (sauf PM 6611)	*PM 6613*	*PM 6614*	*PM 6615*
Gamme de fréquence	5—250 MHz	50—520 MHz	50—1000 MHz
Gamme de tension d'entrée	10 mV_{eff}—12 V_{eff}	10 mV_{eff}—12 V_{eff}	10 mV_{eff}*—12 V_{eff}
dynamique	(—27dBm—+35dBm)	(—27dBm—+35dBm)	(—27dBm*—+35dBm)
Impédance	50 Ω	50 Ω	50 Ω
VSWR	< 2	< 2	< 2
Couplage	AC	AC	AC
Affaiblissement	par atténuateur automatique à diode automatique PIN, maximum 62 dB		
Facteur de division	4	8	16
Protection de surcharge	12 V_{eff}	12 V_{eff}	12 V_{eff}
Tolérance de modulation d'amplitude	98% pour une fréquence de modulation ≤ 5 kHz 30% pour une fréquence de modulation ≥ 1 MHz } tous modèles		
Entrée C (à l'arrière)			
Gamme	1 kHz à 10 MHz		
Sensibilité	500 mV_{eff}		
Couplage	AC		
Impédance	≈ 10 kΩ		
Protection de surcharge	50 V_{eff}		
Oscillateur ext.	Via entrée C.		

C. CARACTÉRISTIQUES DE SORTIE

10 MHz OUT	
Fréquence de sortie	fréquence de l'oscillateur interne (10 MHz)
Niveau de signal	≈ 1 V_{eff} (circuit ouvert)
Impédance de sortie	approximativement 200 Ω (à l'épreuve des courts-circuits)
Couplage	courant alternatif
Affichage	9 chiffres Tube indicateur plat à décharge gazeuse en 7 segments
Témoin de porte (GATE)	Indique que la porte principale est ouverte et que le comptage a lieu. En position STAND BY, la témoin indique que le compteur est raccordé au secteur ou à la tension de batterie.

D. CARACTÉRISTIQUES GÉNÉRALES

Oscillateur	Voir Accessories et notice d'entretien
Alimentation	
Secteur	100—130 V ou 200—260 V, 50 à 400 Hz, 15—25 VA
Batterie externe	Tension +11.8 V à +28 V, consommation max. 1 A—0.5 A respectivement à 12 et à 24 V. Environ 100 mA en position « STAND BY » si le compteur est équipé d'une enceinte thermostatée.
Batterie interne en option	PM 9673
Connecteur	Douilles bananes 4 mm

---

* au-delà de 960 MHz, la sensibilité du PM 6615 peut descendre à 14 mV_{eff} à 1 GHz (—24 dBm).

Conditions d'environnement

Température	
Stockage	—40° C à +70° C —40° C à +50° C (avec option batterie PM 9673)
Fonctionnement	0° C à +50° C (0° C à +40° C avec option batterie PM 9673)
Interférence secteur	meilleure que CISPR
Altitude	15000 m stockage 5000 m en fonctionnement
Humidité	humidité relative 90 % (point de rosée 26° C)
Résistance aux chocs	Conforme aux recommandations IEC 68 Eb
Résistance aux vibrations	Conforme aux recommandations IEC 68 F

Dimensions

Largeur	210 mm
Hauteur	89 mm
Profondeur	325 mm
Poids	2,8 kg env.

III. ACCESSOIRES

1. Accessoires standard (compris à la livraison)

1 câble secteur

1 notice d'emploi et d'entretien

1 fusible 1.6 « action rapide »

1 plaque « 115 V »

2. Accessoires en option

2.1. Oscillateurs

PM 9677 oscillateur standard

PM 9678 TCXO

PM 9679 enceinte thermostatée 1×10^{-7}/mois
PM 9690 enceinte thermostatée 1.5×10^{-9}/24 h

2.2. Unités de sortie

PM 9674 unité de sortie BCD

PM 9675 convertisseur digital/analogique

2.3. Accessoires d'entrée

PM 9351 sonde passive 10 MΩ/11 pF
220 MHz, atténuation 10×

PM 9353 sonde FET, 1 MΩ/3.5 F, 220 MHz

PM 9584 élément de mélange ohmique, 50Ω,
3 douilles BNC

PM 9346 active alimentation pour sonde active

2.4. Câbles coaxiaux

PM 9074 50Ω, BNC—BNC, longueur 1 m

PM 9588 jeu de câbles 50Ω, BNC—BNC :
5 câbles, longueur 20.7 cm
4 câbles, longueur 40.5 cm
3 câbles, longueur 60.3 cm
3 câbles, longueur 198.6 cm

2.5. Câble secteur

PM 9011 câble secteur 3 conducteurs

2.6. 19″ adapteur pour montage en rack
PM 9669/01 pour un compteur
PM 9669/02 pour deux compteurs

2.7. Unité de batterie
PM 9673 unité de batterie interne avec chargeur incorporé

2.8. Sac « toujors prét »
PM 9672

IV. INSTALLATION

1. Alimentation secteur

Le compteur peut être raccordé à deux tensions de secteur, 100—130 V et 200—260 V. La gamme de fréquence est entre 50 à 400 Hz. A la livraison, le compteur est cablé pour la gamme 200 à 260 V.
Pour raccorder le compteur à 100—130 V, changez les connexions du transformateur secteur selon la fig. IV-1, et recouvrez la plaque « 230 V » au moyen de la plaque fournie « 115 V ».



Fig. IV-1 : Connexions du transformateur secteur

2. Mise à la terre

Procédez à la mise à la terre conformément aux règlements de sécurité en vigueur. Deux méthodes sont possibles :

1. par l'intermédiaire de la borne de terre à l'arrière de l'appareil.
2. par l'intermédiaire du câble secteur à trois conducteurs enfiché dans une prise à contacts « terre » protecteurs.

NOTA : N'employez qu'une de ces solutions pour éviter la production de ronflements parasites !

3. Fusibles

L'alimentation est protégée par un fusible thermique sur le transformateur du secteur et un fusible 1.6 A, à action rapide, sur l'unité U1. Voir aussi figure VI-4 sur page 43.

4. Accessoires optionnels

Se référer aux instructions de montage données dans la notice de chaque accessoire.

V. ORGANES DE COMMANDE, INDICATEURS ET RACCORDS

Voir figures VI-1 à VI-5 sur pages 42 et 43

1 DISPLAY TIME

Réglage de la durée d'affichage entre 0.2 et 5 s.
Lorsque le bouton est tiré, la durée d'affichage est infinie.
Lorsque le commutateur est placé en position STAND BY, le compteur est arrêté, à l'exception de l'enceinte thermostatée.
ATTENTION : La tension primaire de l'alimentation est appliquée !

2 GATE

La lampe indique que la porte principale est ouverte et que le comptage a lieu. Le bouton DISPLAY TIME étant en position STAND BY, la lampe GATE rest allumée et indique que l'enceinte thermostatée est en marche.

3 SENSITIVITY

Commande de la sensibilité de l'entrée A. Actionnée, cette commande règle en continu la sensibilité entre 4 V et 200 mV environ. En tirant le bouton, la sensibilité peut être réglée entre 220 mV et 10 mV.

4 ⊓

Pour mesurer des signaux à l'entrée A avec un facteur de forme > 0.75 il faut actionner ce bouton pour assurer un déclenchement fiable.

5 5—250 MHz, PM 6613
50—520 MHz, PM 6614
50 MHz—1 GHz, PM 6615

En poussant le canal B est branché
Sauf sur PM 6611.

6 ⊔

Pour mesurer des signaux à l'entrée A avec un facteur d'utilisation < 0.25, il faut actionner ce bouton pour assurer un déclenchement fiable.

7 ~

Pour mesurer des signaux à l'entrée A avec un facteur d'utilisation 0.25—0.75, il faut actionner ce bouton pour assurer un déclenchement fiable.

7 10 CHECK

Auto-contrôle de l'appareil

8 B

Entrée B. Entrée de signal pour mesure de FREQUENCE et RAPPORT DE FREQUENCE. Gammes de fréquence :
PM 6613, 5 MHz à 250 MHz
PM 6614, 50 MHz à 520 MHz
PM 6615, 50 MHz à 1 GHz
Non sur PM 6611.

9 A

Entrée A. Entrée de signal pour COMPTAGE, FREQUENCE, PERIODE et RAPPORT DE FREQUENCE. Gammes de fréquence de 10 Hz à 80 MHz.

10 < 100 kHz ~

Filtre passe-bas. En mesurant des signaux à forts bruits à l'entrée A avec un facteur d'utilisation ~ 0.5 et une fréquence < 100 kHz le déclenchement est amélioré en poussant ce bouton.

11 Sélecteur de fonction
COUNT A

Le sélecteur étant en cette position, le compteur additionne les impulsions à l'entrée A pendant l'intervalle de temps entre l'enfoncement et le relâchement du bouton START/STOP.

FREQUENCY

Réglage du compteur sur mesure de fréquence.
MHz et kHz sont des unités de mesure liées à l'affichage. 100 Hz, 10 Hz et 0.1 Hz est la résolution du dernier chiffre significatif.

PERIOD A

Réglage sur mesure de la période à l'entrée A.
µs est l'unité de mesure reliée à l'affichage. N = 1, n = 10^2 et n = 10^4 indique le nombre de périodes mesuré.

RATIO A/C
et B/C

Réglage du compteur sur mesure du rapport entre les signaux appliqués aux entrées A et C ou B et C.
n = 10^2 et n = 10^4 sont facteurs de multiplication

12 **MEMORY START/STOP**

En position relâchée, l'information mesurée est mémorisée jusqu'à la fin du prochain cycle de mesure.
En appuyant sur le bouton, l'affichage suit continuellement les compteurs à décades.
En mode COUNT A, opération start/stop.

13 **RESET**

Remise à zéro du compteur à décades et de l'affichage.

Panneau arrière

14

Entrée secteur.

15 **INT.BATT.OFF MAINS/EXT.BATT.**

Déconnecte la batterie interne.
L'appareil est raccordé au secteur ou à la batterie externe.
La batterie interne est chargée lorsque le câble du secteur est connecté.

15 **INT.BATT.ON**

L'appreil est alimenté à partir de la batterie interne. Le secteur ou la batterie externe sont coupés..

16 **INPUT C**

Entrée C. Entrée de signal pour signal externe de base de temps de 1 kHz à 10 MHz et mesure du RAPPORT DE FREQUENCE.

17 **10 MHz OUT**

Sortie pour le signal de l'oscillateur interne.

18 **BCD**

Raccord d'entrée de l'unité BCD.

19 ⏚

Mise à la terre du châssis.

20 —

Raccord du pôle négatif de la batterie externe.

21 +

Raccord du pôle positif de la batterie externe.

22 **INT.STD EXT.STD IN VIA C**

Commute le compteur sur oscillateur interne ou externe.

23

Raccord pour convertisseur continu-alternatif et unité BCD.

VI. MANIPULATION

Voir figures VI-1 à VI-5 sur pages 42 et 43

Généralités

1. Mise en route

1.1. Secteur

Avant de raccorder le compteur au secteur, contrôlez que le transformateur secteur est branché à la tension locale du secteur. Voir chapitre IV, INSTALLATION.
Commutateur MAINS EXT.BATT./INT.BATT.ON en position MAINS EXT.BATT. ⓯.
Raccorder le câble du secteur au compteur à ⓮.
Commutateur DISPLAY TIME ❶ sur ON. Contrôlez que la lampe GATE ❷ et l'affichage sont allumés, signalant que le compteur est branché.

1.2. Batterie externe

Commutateur MAINS EXT.BATTERY/INT.BATT.ON ⓯ en position MAINS EXT.BATTERY.
Raccorder les câbles de la batterie externe à la douille EXT.BATT. 12—24 V « + » ㉑ et « — » ⓴.
Contrôlez que la lampe GATE ❷ et l'affichage sont allumés, signalant que le compteur est branché.

1.3. Batterie interne PM 9673

Commutateur MAINS EXT.BATTERY/INT.BATTERY ON ⓯ en position INT.BATTERY ON.
Contrôlez que la lampe GATE ❷ et l'affichage sont allumés, signalant que le compteur est branché. Un affichage clignotant signale une tension trop basse. Voir notice d'emploi PM 9673, instructions de charge.

2. Temps d'échauffement

Les appareils équipés d'enceinte thermostatée PM 9679 ou PM 9690 ont un temps d'échauffement de moins de 7 minutes, après raccordement au secteur, pour obtenir une stabilité de 10^{-7}. Les compteurs équipés d'oscillateurs PM 9677 ou PM 9678 (TCXO) sont prêts à l'emploi dès raccordement au secteur. Normalement, l'appareil est branché en position STAND BY ❶. Dans ce cas, aucun temps d'échauffement n'est nécessaire, quelque soit l'oscillateur employé.

3. Fréquences externes standard

On peut utiliser d'autres fréquences standard à la place de la fréquence de 10 MHz de l'oscillateur interne. Pour un temps de résolution de 100 ns, il faut utiliser les 10 MHz.
En employant 1 MHz au lieu de 10 MHz, il faut décaler la virgule d'une position vers la gauche pour interpréter correctement l'affichage. Pour régler le compteur sur un standard externe, mettre le cavalier interne SK 131 ㉒ ou le commutateur SK 22 ㉒ au panneau arrière en position EXT.STD.

Mesures

Voir figures VI-1 à VI-5 sur pages 42 et 43

4. CONTRÔLE

1. Poussez les deux boutons CHECK ❼ ❿.
2. Commutateur DISPLAY TIME ❶ en position centrale.
3. Tournez le sélecteur ⓫ et relevez les valeurs d'affichage ci-après :

Fonction	Lecture (± 1 chiffre)
FREQ 100 Hz	10.0000
FREQ 10 Hz	10.00000
FREQ 1 Hz	10000.000
FREQ 0.1 Hz	10000.0000
PERIOD n = 1	00000000.1
PERIOD n = 10^2	0.100
PERIOD n = 10^4	0.10000

4. Commutateur ⓫ en position COUNT A.
5. Poussez le bouton START/STOP ⓬ : le compteur totalise les impulsions d'entrée et l'affichage suit continuellement le comptage jusqu'au relâchement du bouton START/STOP ⓬.

5. FREQ. A

1. DISPLAY TIME ❶ en position centrale.
2. Sélecteur de fonction ⓫ sur une des quatre positions de fréquence qui correspond à la résolution voulue de la mesure.
3. Appliquez le signal à mesurer à l'entrée A ❾.
4. Adaptez l'entrée du compteur à la fréquence et au facteur de forme du signal à mesurer en actionnant un des boutons ❹ ❻ ❼ ❿.
5. Réglez la commande SENSITIVITY ❸ pour stabiliser l'affichage.

6. FREQ. B (sauf sur PM 6611)

1. Commutateur DISPLAY TIME ❶ en position centrale.
2. Branchez le canal B en enfonçant le bouton ❺.
3. Sélecteur de fonction ⓫ sur une des quatre positions de fréquence qui correspond à la resolution voulue.
4. Appliquez le signal à mesurer à l'entrée B ❾.

7. PERIOD A

1. Sélecteur de fonction ⓫ sur une des trois positions de la PERIOD A en fonction du nombre voulu de périodes à mesurer.
2. Appliquez l'entrée du compteur à la fréquence et au facteur de forme du signal à mesurer en actionnant un des boutons ❹ ❻ ❼ ❿.

8. RAPPORT DE FREQUENCE A/C*

1. Sélecteur de fonction ⓫ sur une des deux positions RATIO en fonction du nombre voulu de décimals sur l'affichage.
2. DISPLAY TIME ❶ en position centrale.
3. Appliquez le signal avec la plus haute fréquence à l'entrée A ❾.
4. Ajustez l'entrée du compteur à la fréquence et au facteur de forme du signal à mesurer en actionnant un des boutons ❹ ❻ ❼ ❿.
5. Appliquez le signal avec la plus basse fréquence à l'entrée C ⓰.
6. Régler la commande SENSITIVITY ❸ pour stabiliser l'affichage.

9. RAPPORT DE FREQUENCE B/C*

(non sur PM 6611)

1. Sélecteur de fonction ⓫ sur une des deux positions RATIO en fonction du nombre voulu de décimales sur l'affichage.
2. DISPLAY TIME ❶ en position centrale.
3. Appliquez le signal avec la plus haute fréquence à l'entrée B ❽.
4. Branchez le canal B en actionnant le bouton ❺.
5. Appliquez le signal avec la plus basse fréquence à l'entrée C ⓰.

10. TOTALISATION (COUNT A)

1. Sélecteur de fonction ⓫ en position COUNT A.
2. Appliquez le signal à mesurer à l'entrée A ❾.
3. Ajustez l'entrée du compteur à la fréquence et au facteur de forme du signal à mesurer en actionnant un des boutons ❹ ❻ ❼ ❿.
4. DISPLAY TIME ❶ en position centrale.
5. Enfoncez le bouton START/STOP.
6. Une fois le bouton START/STOP ⓬ enfoncé, le compteur commence à totaliser les impulsions d'entrée jusqu'au relâchement du bouton START/STOP ⓬. L'affichage indique le nombre d'impulsions comptées pendant l'intervalle de temps écoule entre l'enfoncement et le relâchement du bouton START/STOP ⓬.

*** NOTA**

Les facteurs multiplicateurs 10^5, 10^6, 10^7 et 10^8 sont possibles en mode de fréquence lorsqu'on utilise l'entrée C comme entrée de la base de temps externe. (Le cavalier interne SK 131 ㉗ ou le commutateur au panneau arrière en position EXT.STD.)
Le point décimal est alors incorrectement positionné.



Figure VI-1. Front panel PM 6611
Abbildung VI-1. Frontseite PM 6611
Figure VI-1. Vue avant PM 6611



Figure VI-3. Rear panel
Abbildung VI-3. Rückseite
Figure VI-3. Vue arrière

Figure VI-4. Top view
Abbildung VI-4. Ansicht von oben
Figure VI-4. Vue dessus



Figure VI-2. Front panel PM 6613, PM 6614 and PM 6615
Abbildung VI-2. Frontseite PM 6613, PM 6614 und PM 6615
Figure VI-2. Vue avant PM 6613, PM 6614 et PM 6615



Figure VI-5. Bottom view
Abbildung VI-5. Unteransicht
Figure VI-5. Vue dessous

Service manual

CONTENTS

VII. Survey of connectors, sockets, switches and potentiometers 51

VIII. Circuit description 52

1. 80 MHz input amplifier 52
2. Unit 2 PM 6613 52
3. Unit 2 PM 6614 53
4. Unit 2 PM 6615 53
5. Time base divider 53
   - 5.1. General 53
   - 5.2. Synchronized preset 55
   - 5.3. Main gate and display time control 56
6. Decimal counting unit and display unit 58
   - 6.1. General 58
   - 6.2. 80 MHz decade 58
   - 6.3. LOCMOS quad decades IC 175 and IC 176 60
   - 6.4. Blanking 60
   - 6.5. Display scanning 62
   - 6.6. Decimal point setting 62
7. Power supply 62
   - 7.1. General 62
   - 7.2. Power input circuit 62
   - 7.3. Overvoltage protection 62
   - 7.4. DC to DC converter 64
   - 7.5. Output voltage regulation circuit 64

IX. Performance check 65

1. Survey of check points 65
2. Test equipment and accessories 66
3. FREQUENCY and PERIOD A 67
4. RESET 67
5. DISPLAY TIME 67
6. MEMORY 67
7. PERIOD A 67
8. COUNT A START/STOP 67
9. RATIO A/C 68
10. RATIO B/C PM 6613. Not applicable for PM 6611 68
11. RATIO B/C PM 6614 and PM 6615. Not applicable for PM 6611. 68
12. INPUT A with low frequency filter, trigger mode selectors and attenuator 69
13. FREQUENCY A: Frequency response, sensitivity and sine wave trigger selector 69
14. INPUT A: Low frequency filter and square wave trigger selector 69
15. INPUT A: Attenuator 70
16. INPUT B: Frequency response, sensitivity and automatic gain control. Not applicable for PM 6611 71
17. INPUT C: Frequency range and sensitivity 71
18. 10 MHz OUT 72
19. Temperature compensated crystal oscillator PM 9678 72
20. Oven-enclosed oscillators PM 9679 and PM 9690 72
21. Standard oscillator PM 9677 72

X. Internal checks and adjustments 73

1. Location of trimmers and check points 73
2. Test equipment 73
3. D.C. voltages 73
4. D.C. balance channel A 73
5. Frequency compensation channel A 73

XI. Oscillators PM 9677, PM 9678, PM 9679 and PM 9690 75

1. General 76
2. Technical data 76
3. Frequency adjustment PM 9677 77
4. Frequency adjustment PM 9678 77
5. Frequency adjustment PM 9679 77
6. Frequency adjustment PM 9690 77
7. Repair of oscillators PM 9679 and PM 9690 77
8. Pin configuration 77
9. Circuit diagram, component layout and spare parts list PM 9677 78
10. Circuit diagram, component layout and spare parts list PM 9678 79

XII. Replacing parts 80

1. Push-button switches 80
2. Text plate and front rim 80
3. Handle 80
4. Power supply 80

XIII. Spare parts, faultfinding, testpoints and circuit diagrams 81

1. Spare parts Unit 1 (all models) 82
2. Spare parts Unit 2 (PM 6613 only) 84
3. Spare parts Unit 2 (PM 6614 only) 85
4. Spare parts Unit 2 (PM 6615 only) 86
5. Mechanical parts (all models) 87
6. Testconditions 88
7. Circuit diagrams 89

List of figures

VIII-1 Preset sync circuit 55
VIII-2 Timing diagram, main gate and display time control 57
VIII-3 80 MHz decade circuit and timing diagram 59
VIII-4 Timing diagram of display presentation 61
VIII-5 Block diagram of LOCMOS quad decade 60
VIII-6 Timing diagram of display scanning principle and blanking pulse generation 63
VIII-7 Current paths in DC-to-DC converter 64
IX-1 10 MHz out 72
XI-1 Component layout PM 9677 78
XI-2 Circuit diagram PM 9677 78
XI-3 Component layout PM 9678 79
XI-4 Circuit diagram PM 9678 79
XII-1 Replacing push-button switch 80
XII-2 Removing the front rim 80
XIII-1 Block diagram 90
XIII-2 Component layout, unit 1 95
XIII-3 Circuit diagram, 80 MHz input amplifier 99
XIII-4 Circuit diagram, time base divider 104
XIII-5 Circuit diagram, decimal counting unit and display 110
XIII-6 Circuit diagram, power supply 115
XIII-7 Component layout, unit 2 PM 6613 117
XIII-8 Circuit diagram, unit 2 PM 6613 120
XIII-9 Component side, unit 2 PM 6614 123
XIII-10 Soldering side, unit 2 PM 6614 123
XIII-11 Circuit diagram, unit 2 PM 6614 125
XIII-12 Component side, unit 2 PM 6615 127
XIII-13 Soldering side, unit 2 PM 6615 127
XIII-14 Circuit diagram, unit 2 PM 6615. 129

VII. SURVEY OF CONNECTORS, SOCKETS, SWITCHES AND POTENTIOMETERS

BU 1	Input socket channel A
BU 2	Input socket channel B. Not present in PM 6611
BU 21	Input socket plus pole external battery
BU 22	Input socket minus pole external battery
BU 23	Mains input socket
BU 24	Input socket channel C
BU 25	10 MHz output socket
BU 26	Earth clamp
BU 102	Connects unit U2 to unit U1. Combined connector: male and female.. Not present in PM 6611
BU 103	Connects oscillator to unit U1. Male
BU 104	Jumper connector for d.c. voltages. Male
BU 105	Connector for internal battery. Male
BU 106	Connector for BCD and D/A converter. Female
BU 107	Connector for d.c. voltages. Female
BU 201	Connects unit U2 to unit U1. Female. Not present in PM 6611
SK 22	EXTERNAL/INTERNAL STANDARD switch
SK 101	DISPLAY TIME switch
SK 102	STAND BY switch
SK 103	RESET switch
SK 104	MEMORY and START/STOP switch
SK 105	FUNCTION selector switch
SK 106	SENSITIVITY switch
SK 107	LOW FREQUENCY FILTER switch
SK 108	SINE WAVE triggering switch
SK 109	POSITIVE PULSE triggering switch
SK 110	NEGATIVE PULSE triggering switch
SK 111	CHANNEL B switch. Not present in PM 6611
SK 121	INTERNAL BATTERY/MAINS OR EXTERNAL BATTERY switch
SK 131	Jumper connector for EXTERNAL/INTERNAL STANDARD (only present in earlier version of the instrument)
R 107	SENSITIVITY potentiometer
R 1157	DISPLAY TIME potentiometer

VIII. CIRCUIT DESCRIPTION

1. 80 MHz input amplifier

Refer to the circuit diagram fig. XIII-3.

The 80 MHz input amplifier is identical for all models PM 6611, PM 6613, PM 6614 and PM 6615. One only exception is switch SK 111 which is not present in PM 6611.

The measuring signal enters the amplifier at BNC socket INPUT A. The DC component of the signal is blocked by C 101. A two-position attenuator R 101, R 139, C 102, C 103 is controlled by switch SK 106. C 102 sets the frequency compensation.

Input protection is provided by R 102, C 104, R 103 and clipping diodes GR 101, 102, 103 and 106. Field-effect transistor TS 101 converts the input impedance together with emitter-follower TS 102 providing a low-ohmic output to the amplifier circuits. R 111, L 103 and C 132 form a 100 kHz low-pass filter which is operated with switch SK 107. R 107 sets the input sensitivity. When SK 107 is released, SK 108 has no function.

However, when both switches are depressed at the same time, the time base reference signal from IC 123:8 (see circuit diagram Time Base Dividers) is applied to the amplifier section via R 110, R 124, SK 107:3, 2 and SK 108:6, 5.

The next switch SK 111, which is not present in PM 6611, controls the prescaler unit U2 of PM 6613, PM 6614, or PM 6615. When SK 111 is released, the prescaler section is inoperative, because a LOW CLEAR level is provided from SK 111:4, via BU 102:6 and BU 201:6 to the D flip-flops of the prescaler. See the relevant circuit diagram of unit U2. Moreover, since SK 111:6 is open, a HIGH level is fed via BU 102:5 and BU 201:5 to the supply voltage control transistor in U2. The supply voltage of U2 is then interrupted.

When SK 111 is depressed, the signal path of the 80 MHz amplifier is shorted to earth via SK 111:2 and 3. The supply voltage of U2 is switched in and the CLEAR inputs of the prescaler D flip-flops go HIGH. See also the description of the Time Base Divider section.

Switches SK 110 and SK 109 are principally polarity shifters selecting the normal (12) or inverting (13) input of line receiver IC 101.

When the input signal is a sine wave or pulses with the duty factor 25 to 75 %, both SK 110 and SK 109 should be released. The signal path is then from SK 108 through SK 111, C 117, pins 5 and 4 of SK 110, and R 116 to the non-inverting input 12 of the first amplifier IC 101. The signal is available at both outputs 14 and 15.

When the input signal is a pulse train with a duty factor exceeding 75 %, switch SK 110 should be depressed. The signal now goes through pins 5 and 6 of SK 110 and via R 115 to the inverting input 13 of IC 101. The dc reference level is shifted outside the triggering window of the amplifier because pins 2 and 3 of SK 110 are connecting R 112 to earth.

SK 109 should be depressed when the input signal is a pulse train with duty factor below 25 %. Notice that SK 109 and SK 110 are interacting, so that SK 110 is automatically released when SK 109 is depressed. The signal path is now via C 117, pins 5 and 4 of SK 110, and R 116 to input 12 of IC 101. The only active function of SK 109 is to connect R 112 to earth to set the dc reference level of IC 101 outside the trigger window. Symmetrical feedback of the first amplifier stage IC 101 is provided by R 113 and R 114. At outputs 14 and 15, R 118 and R 119 are pull-down resistors for the emitter follower outputs.

The next amplifier stage of IC 101 with inputs 9 and 10 is not symmetrically fed back to prevent interference from Schmitt trigger TS 104, TS 103, from reaching the amplifier.

Input 10 also accepts the prescaled signal from unit U2 of PM 6613, PM 6614 or PM 6615. Variable resistor R 127 sets the d.c. balance of the amplifier.

Output 7 provides the signal for Schmitt trigger TS 104, TS 103. GR 110 ensures temperature stabilisation. TS 105 is interfacing the Schmitt trigger output to TTL level. Before the choke L 101 at the collector of TS 105, the signal A 1 is taken out to the DCU. L 101 is filtering frequencies above 10 MHz. Output signal A 2 is used as the time base signal in the PERIOD mode.

2. Unit U2, PM 6613

Refer to the circuit diagram fig. XIII-8.

Unit U2 contains the 250 MHz amplifier and prescaler circuits, and also two D flip-flops IC 201 dividing the time base signal generated on unit U1.

The signal to be measured enters the input amplifier at socket BU 2. After AC coupling capacitor C 201, a resistive atteuator network R 201 . . . R 204 is incorporated which maintains he VSWR of the input and also serves as a series impedance for the PIN diode attentuator GR 201 and GR 202. Schottky diodes GR 203 and GR 204 are clipping the signal but generate also current to the PIN diodes which provide automatically the proper attenuation of high-amplitude signals.

At low amplitude the signal passes this first PIN diode attenuator unchanged to the next PIN diode attenuator GR 205 . . . GR 207. Here the amplitude is reduced further before the signal is entering the input amplifier. The input amplifier consists of four cascade transistors TS 202 . . . TS 205. At the collector of TS 205, the signal is tapped off through C 212 and symmetrically detected by GR 209, 210. The detected negative and positive half-periods are fed to two operational amplifiers IC 202 and IC 203. IC 202 is the Automatic Gain Control amplifier connected as a Miller integrator. It is baised by a current supplied from the +12 V line through R 212, GR 209, GR 210 and R 215.

When the detected level is sufficient, IC 202 starts controlling the PIN diode attenuator GR 205 . . . GR 207. Transistor TS 201 ensures a linear attenuator response within the input signal range.

A special case is if the measuring signal level is very high at low frequencies so that TS 205 becomes saturated. This is detected by diodes GR 212, 213 which are biasing the AGC amplifier IC 202. The PIN

diode attenuator GR 205 . . . 207 then reduces the amplitude to a proper level. The detected signal from GR 209, 210 is also fed to operationel amplifier IC 203 performing a Schmitt trigger function. When no measuring signal is present or at a low detected level, output IC 203:6 is positive. TS 207 is then turned on, shorts the output line to earth, and turns off TS 206. When the detected signal from GR 209, 210 has reached a sufficient level, IC 203:6 goes LOW and TS 207 is turned off.
The measuring signal goes from TS 205 via C 219 and C 234 — R 226 to input 7 of divide-by-four circuit IC 204. The second input 6 is DC reference and diodes GR 214, GR 215 are limiters. The divided signal at IC 204:3 is fed via TS 206 to the output line BU 201:1 which is connected to BU 102:1 in the 80 MHz input amplifier. TS 208 is the supply voltage switch transistor described in section "80 MHz input amplifier". TS 208 also controls the —5.2 V switch TS 209. IC 201 contains the both D flip-flops providing the division by 4 of the time base signal as described in section "Time Base Dividers".

3. PM 6614, Unit U2

Refer to the circuit diagram fig. XIII-11.

The input conditioning section of the 520 MHz amplifier up to IC 201 and the AGC and Schmitt trigger circuits are principally the same as in the 250 MHz amplifier of PM 6613. Refer to the description.
After input conditioning, the measuring signal is applied to two cascade wide-band amplifiers IC 201 and IC 202. The signal level at IC 202 is detected by GR 209, GR 210 controlling the AGC amplifier IC 204 and Schmitt trigger IC 205.
Via R 213, C 213 and amplifier TS 203 the signal is fed to input 10 of divide-by-eight circuit IC 203. Output 1 provides the divided signal to the 80 MHz input omplifier, BU 102.
TS 202 is controlled by switch SK 111 (see the circuit diagram of 80 MHz input amplifier). When the switch is released, the level at BU 201:5, PRESCALER, goes HIGH which turns TS 202 off. Via R 230 and GR 211, also TS 205 is switched off. No supply voltage for the amplifier is present until switch SK 111 is depressed and BU 201:5 goes LOW.
The two D flip-flops of IC 206 and one D flip-flop of IC 207 provide the division by 8 of the time base frequency TB 1. Refer to the description of the Time Base Divider.

4. PM 6615, Unit U2

Refer to the circuit diagram fig. XIII-14.

The input conditioning section of the 1 GHz amplifier up to IC 201 and the AGC and Schmitt trigger circuits are principally the same as in the 250 MHz amplifier of PM 6613. Refer to that description.
After input conditioning, the measuring signal is applied to two cascade wide-band amplifiers IC 201 and IC 202. The signal level at IC 202:7 is detected by GR 209, GR 210 controlling the AGC amplifier IC 204 and Schmitt trigger IC 205.
Via R 213, C 213 and amplifier TS 203, the signal is fed to input 4 of divide-by-four circuit IC 203. The complementary outputs 10 and 11 of this circuit provide the signal to the next 4-divider IC 208 via zeners GR 214, GR 215. These diodes are interfacing the +1 V output of IC 203 with the —3 V input requirement of IC 208. The measuring signal frequencty, now divided by 16, is fed via TS 206 to the output line BU 201:1 which is connected with BU 102:1 to the 80 MHz input amplifier.
TS 202 is controlled by switch SK 111 (see the circuit diagram of the 80 MHz input amplifier). When the switch is released, the level at BU 201:5, PRESCALER, goes HIGH which turns TS 202 off. Via R 230 and GR 211 also TS 205 is switched off. No supply voltage for the amplifier is present until SK 111 is depressed and BU 201:5 goes LOW.
The four D flip-flops of IC 206 and IC 207 provide the division by 16 of the time base frequency TB 1. Refer to the description of the Time Base Divider.

5. Time base divider

5.1. General (see circuit diagram fig. XIII-4)

A dual line receiver IC 120 is used to transfer the internal or external time base reference signals to the time base divider section.
The line receiver consists of two identical stages, each with a differential amplifier converting the input signal into appropriate TTL level, and a NAND gate controlled by the INT/EXT switch and the Function switch SK 105.
In the FREQUENCY mode using the internal oscillator, the 10 MHz signal from BU 103:5 is fed to input 2 of IC 120. After amplification, the signal is fed to the NAND gate of IC 120 being enabled because the two control inputs 5 and 6 of the gate are HIGH. Any signal applied to INPUT C is blocked at the second NAND gate of IC 120 because control input IC 120:8 has a LOW state originating from NAND gate 1/4 IC 122:6. From output IC 120:4 the 10 MHz signal is applied to input 9 of NAND gate IC 123. The second input 10 of this gate is HIGH in the FREQ. mode. When an external time base is used or in the RATIO mode the signal applied to BU 24, INPUT C, is fed to terminal 11 of the line receiver IC 120.
The INT/EXT switch or the Function switch (RATIO) SK 105 inhibits the internal 10 MHz signal because control input IC 120:5 goes LOW. Simultaneously, gate IC 122:6 provides a HIGH state to input IC 120:8 which is enabling the NAND gate. The INPUT C signal can then pass through and via IC 120:9 reach input 10 of NAND IC 123.
Either the 10 MHz signal or the INPUT C signal will be fed from IC 123:8 to the 10 MHz OUT connector BU 25 and to input 4 of AND-NOR configuration ½ IC 121. In all modes except PERIOD mode, control inputs IC 121:5 is HIGH and IC 121:2 is LOW. This means that the measuring signal from the 80 MHz input, used as the time base signal in he PERIOD mode, is inhibited whereas the ordinary time base signal at IC 121:4 can pass through and enter the time base divider section. Via output IC 122:11 and R 134 the signal is fed to the time base dividers consisting of two LOCMOS quad decade counters IC 124 and IC 125. The function of these circuits is described under section 6. Decimal counting unit and Display.

The division factor is set with the Function switch SK 105 which controls the Decade Select inputs indicated M 0, M 1 and the Enable inputs as illustrated in the truth table below.

The divided signal corresponds to the D bit of the relevant decade counter and is available at terminal 18 of each circuit IC 124 or IC 125. Via transistor TS 120 it is fed to the AND-NOR gate configuration IC 121, input 13. The second input 1 is permanently HIGH except in the PERIOD n = 1 and COUNT A modes. In these modes input IC 121:10 is HIGH allowing the time base signal from IC 121:6 to pass through to IC 121:8.

Next, the time base signal is gated through NAND gate IC 123 to NOR gate IC 126:2. The signal is also taken out via BU 102:3 indicated TB 1 to the B input amplifier U2 of either PM 6613, PM 6614 or PM 6615. After prescaling, the time base signal is fed back as TB 2 to BU 102:2 and is applied to IC 126:9. When input B is used, this signal is gated through IC 126 to control the Main Gate flip-flop. This is achieved when switch SK 111 in the 80 MHz input amplifier is depressed which generates a disabling "1" at IC 126:3. Then the normal time base signal can not pass through until after prescaling when it is applied to IC 126:8, 9. In PM 6611, which has no B input amplifier, a pull-up resistor R 1131 is included at IC 126:8, 9.

The time base signal, normal or prescaled, is applied to clock input 3 of the Main Gate flip-flop IC 183, which is controlling the main gate via complementary Q output 6. The Q output 5 controls the Gate indicator LED GR 189 via monostable multivibrator IC 182 and transistor TS 170. The second flip-flop of IC 183 is clocked at terminal 11 by the Main Gate flip-flop and is used as the Display Time flip-flop.

MODE		ENABLE IC 124	ENABLE IC 125	DECADE SELECT INPUTS		SELECT DECADE OF	
				M 0	M 1	IC 124	IC 125
COUNT A		L	H	H	L		D 2
FREQ. A	100 Hz	L	H	L	L		D 1
	10 Hz	L	H	H	L		D 2
	1 Hz	L	H	L	H		D 3
	0.1 Hz	L	H	H	H		D 4
PERIOD A	n = 1	L	H	H	H		D 4
	$n = 10^2$	H	L	H	L	D 2	
	$n = 10^4$	H	L	H	H	D 4	
RATIO	$n = 10^2$	H	L	H	L	D 2	
	$n = 10^4$	H	L	H	L	D 4	

H = HIGH level, L = LOW level.

5.2. Synchronized preset

Refer to the simplified diagram fig. VIII-1.
During the display time interval, the time base dividers are preset to 9999. When the display time interval is ended and the RESET signal goes HIGH, the next clock pulse will trigger the decade counters of the time base dividers. Randomly, the display time interval may end during a clock pulse which might imply uncertain triggering of the dividers. To prevent this, the preset function is synchronized to the leading edge of he clock pulse.
The circuit achieving this consists of NAND gates IC 123 forming a latch configuration and NAND gate IC 122 with output terminal 3. The CLOCK signal applied to IC 122:12, 13 is also fed to IC 123:12. The RESET signal is applied to inputs IC 123:5 and IC 122:2. This means that the latch is controlled by the RESET signal. For example, when the RESET signal is LOW, output IC 122:3 providing the PRESET signal to IC 124:12 is HIGH, independent of the state of the CLOCK signal.

However, output IC 122:3 PRESET, goes LOW only when both inputs 1 and 2 go HIGH. This means, that when RESET goes HIGH during the time the CLOCK signal is also HIGH, input IC 122:1 is still LOW and the PRESET signal at IC 122:3 HIGH. But when the CLOCK signal goes LOW, the PRESET signal will be LOW.



Fig. VIII-1. Preset sync circuit

5.3. Main gate and display time control

IC 183 is a dual D-flip-flop, containing the Main Gate FF and the Display FF. Both flip-flops are triggered by the positive going edge of their clock signal.
In all operating modes except COUNT A, a time base signal is applied to the clock input 3 of the Main Gate FF. The complementary output $\overline{Q}$, pin 6, is connected to the main gate in the DCU section. The main gate is closed when $\overline{Q}$ is HIGH, but will open when $\overline{Q}$ goes LOW.
Assume that $\overline{Q}$, pin 6, is HIGH. Then the D input pin 2 is also HIGH. At the next positive-going edge of the time base signal, output $\overline{Q}$ goes LOW and the main gate opens, i.e. the counting interval starts. The second output IC 183:5, Q, controls the Gate LED Multivibrator via input 13 of NOR gate IC 182. This monostable multivibrator controls the Gate LED GR 189 via TS 170. The LED can also be turned on by the front panel DISPLAY TIME switch when set to the STAND BY position. The monostable multivibrator is stretching the pulse at the shortest gate time settings so that the blinking of the LED becomes visible.
At the next positive-going edge of the clock signal at IC 183:3, the Main Gate flip-flop switches over, the complementary output IC 183:6 goes HIGH and the main gate is closed.
At this moment the display time interval starts. During this interval a TRANSFER pulse should be generated to the decade counters in the decimal counting unit, and a RESET pulse should be generated before the next counting interval starts.
The timing diagram fig. VIII-2 shows the sequence of these events. The Display Time flip-flop IC 183 is triggered by the positive-going edge of the MAIN-GATE signal from IC 183:6. Output IC 183:9 goes HIGH and provides a LOW CLEAR pulse to the Main Gate flip-flop input 1 via NOR gate IC 184:10. The output state of the Main Gate flip-flop is then maintained. The complementary output IC 183:8 of the Display Time flip-flop is LOW which normally would have set NOR gate output IC 185:10 to a HIGH level, causing the generation of a TRANSFER pulse via C 173 and R 1156. However, an INHIBIT LOW signal is assumed to be applied (e.g. from an automatic measuring system) via BU 106:5. Via IC 185:2 and 9, output 10 is latched to a LOW level until the INHIBIT signal goes HIGH. Then IC 185:10 goes HIGH and is latched to this state by the feed-back to input 3 eliminating the influence of another INHIBIT LOW signal that may appear. The positive-going edge is differentiated by C 173—R 1156, and a TRANSFER pulse is generated and fed to the DCU via IC 184:6. The positive-going edge from IC 185:10 is also fed to the Display Time multivibrator input IC 182:6 via R 1156. Capacitator C 172 starts charging and at the threshold level of IC 182:6, the multivibrator is triggered. Output IC 177:10 generates a sloping pulse which is converted to a proper RESET pulse at NOR gate output IC 178:13. Inverter IC 178:1 provides the RESET pulse to the DCU.

The RESET pulse is resetting the Time Base Dividers IC 124 and IC 125 via NAND gate IC 122, output 3. The Display Time flip-flop IC 183 is cleared by the RESET pulse at input 13, i.e. output IC 183:9 goes LOW. When the RESET pulse ends, the time base dividers generate clock pulses for the Main Gate flip-flop and the cycle is repeated. However, as illustrated in the second sequence of the timing diagram fig. VIII-2, the TRANSFER pulse appears immediately when the main gate is closing.

A third alternative occurs when the MEMORY push-button switch SK 104 is depressed, i.e. the memory is switched off. Then the main gate flip-flop output IC 183:6 is directly connected via pins 3 and 2 of SK 104 to input 5 of NAND gate IC 184. The TRANSFER pulse will then coincide with the main gate pulse plus the additional short pulse at the beginning of display time interval. Manual RESET is generated by push-button SK 103. Latch configuration IC 184:3 and 11 prevents contact bounce interference.



Fig. VIII-2. Timing diagram, main gate and display time control

6. Decimal counting unit—DCU—and display unit

6.1. General

Refer to the circuit diagram fig. XIII-5.
The DCU consists of an 80 MHz decade IC 170, IC 171 for the least significant digit and two LOCMOS circuits IC 175, IC 176 each containing four complete decades. An address counter IC 179 generates the ENABLE signals for the 80 MHz decade the quad decades IC 175, IC 176 and also the scanning pulse sequence for the display via a BCD to 1 of 10 decoder IC 180.
The four-line BCD code provided by the decades is applied to the display via a BCD to 7 segment decoder IC 181. The outputs of this circuit are connected each to one segment of the 9 parallel connected digits including the decimal point.

6.2. 80 MHz decade

Refer to the circuit diagram fig. XIII-5 and the timing diagram fig. VIII-3.
2 D-type flip-flops IC 170, two edge-triggered JK flip-flops and a decoder NOR gate IC 178 form the 80 MHz decade. The input signal comes from the main gate IC 172 and triggers the first D flip-flop IC 170 which generates the A bit of the four-line BCD code. Next, the flip-flop IC 171 generates the B bit. When triggered by the negative edge of the A signal and the JK inputs are HIGH, i.e. when the complementary D bit at input J is HIGH. The K input is permanently HIGH.
The third flip-flop in the row, also a JK IC 171, produces the CARRY signal when triggered by the negative edge of the A pulse and the output of this flip-flop changes according to the state of the JK inputs at the time of triggering.
The fourth flip-flop, a D-type IC 170, produce the D bit at IC 170:9 when triggered by the complementary A bit assuming the B bit applied to the Data input IC 170:12 is HIGH.

Both the CARRY and D signals are applied to NOR gate decoder 1/4 IC 178 which generates the C bit as indicated in the timing diagram fig. VIII-3.
The four-line BCD information from the 80 MHz decade is then stored in the latch flip-flop IC 173. When the gate time ends, a TRANSFER pulse enables the latch which supplies the BCD data to the NAND gate network IC 174. These gates are inhibited until the ENABLE signal — D = HIGH — arrives from the address counter IC 179. When enabled, the BCD information are transferred via the data bus line to the BCD to 7 segment decoder IC 181. Refer to the timing diagram fig. VIII-4.





Fig. VIII-3. 80 MHz decade circuit and timing diagram

6.3. LOCMOS quad decades IC 175, IC 176

The CARRY signal from the 80 MHz decade is also used to clock the first decade counter of the LOCMOS circuit IC 175. This decade is referred to as D1 in the timing diagram fig. VIII-4.
DO indicates the 80 MHz decade just described. Each of the four decades contained in the LOCMOS circuit IC 175 or IC 176 functions principally as the 80 MHz decade. However, a brief look at the block diagram fig. VIII-5 will help understanding the special features. The PRESET input is permanently LOW and inactive because it is connected to—2.1 V. The CLOCK signal enters at input 14 and triggers the decades whose outputs are stored in the corresponding latches. When the TRANSFER pulse arrives, the information is fed to the multiplexer. Depending on the states of the Digit Select Inputs M0, M1, M2, the data of one of the decades is transferred to the BCD outputs provided the ENABLE input is HIGH. The truth table in figure VIII-5 indicates the relevant input states. Inputs M0 and M1 are addressed with BCD bits A and B respectively from the Address Counter IC 179. Input M2 is connected to—2.1 V and thus permanently LOW. The ENABLE signal to the first quad decade IC 175 is generated by NOR gate 1/4 IC 182 whose inputs are the C and D bits of the Address Counter IC 179. Thus, when both C and D are LOW as indicated in the timing diagram fig. VIII-4 the ENABLE signal to IC 175 goes HIGH. Assuming that both A and B of the Address Counter are LOW, decade D1 will provide its information to the BCD output and further to the BCD to 7-segment decoder IC 181. In the example given in the timing diagram fig. VIII-4 the digit next to the LSD will display a "2".
The next address from IC 179 will be A = HIGH, which means that the data of decade D2 is transferred to the BCD outputs and digit "0" is displayed. The sequence goes on until decade D4 has been selected. Then the ENABLE signal of IC 175 goes LOW because the C bit of the Address Counter goes HIGH. Instead, the ENABLE signal for quad decade IC 176 goes HIGH. Now the sequence starts again with the Digit Select Inputs M0, M1, M2 all being LOW thus selecting decade D5. Finally, decade D8 is selected corresponding to the Most Significant Digit, MSD.

6.4. Blanking

As indicated in the timing diagram fig. VIII-4, the output signals from the BCD to 7-segment decoder IC 181 contain blanking pulses between each digit information. The blanking is necessary to prevent unwanted glowing of unactivated segments of the display digit, and also to avoid the so-called streamers, which are glowings appearing between adjacent digits. In instruments with serial prefix 1, the blanking pulses are fed to the BCD to 7-segment decoder IC 181 only. From serial prefix 2, the blanking pulses are also applied to the anodes of the display B 101 via transistors TS 180 . . . TS 188.
The timing diagram fig. VIII-6 indicates how the blinking pulses are generated.
The pulses of the display multivibrator 2/6 IC 177 terminal 15 are fed to differentiating network R 191—C 140 via R 190 to the base of transistor TS 139. Its collector is connected to the blanking input 1 of IC 181 and, in instruments with serial prefix 2, via R 189 to the emitters of display driving transistors TS 180 . . . TS 188.
When the pulse on the base of TS 139 is positive the transistor will be turned off and the programmed current in the cathode driver will be zero.



Fig. VIII-5. Block diagram of LOCMOS quad decade



Fig. VIII-4. Timing diagram of display presentation

6.5. Display scanning

The display is scanned from the least significant digit —LSD— to the most significant digit—MSD. Only one digit lights at a time.
The pulse sequence controlling the driver transistors for the display digits is obtained from a BCD to 1 of 10 decoder IC 180 supplied with the four-line BCD information generated by the address counter IC 179. The timing diagram fig. VIII-6 illustrates how the digits are scanned. When output terminal 10 of the decoder IC 180 goes LOW, transistor TS 188 turns on and current can flow to the enabled segments of the least significant digit. Capacitor C 188 is connected between —50 V and +120 V and is changed to about 170 V which is sufficient to initiate a discharge of the segments of the display digit. The digit is presented during about 200 μs. At the next address from IC 179, output IC 180:10 goes HIGH again and output IC 180:1 goes LOW which is activating the next digit via TS 187. In the meantime, however, a 12 μs blanking pulse is generated by TS 139 which turns off all digits before the next digit segments are activated.
The scanning of the digits goes on until the most significant digit is turned on. Then the cycle starts all over again.

6.6. Decimal point setting

The Function Selector SK 105, controls the decimal point positioning in the display.
The decimal point input DP of the BCD to 7-segment decoder IC 181 is connected to pin 3 of SK 105 wafer 1. As indicated in the table in the circuit diagram fig. XIII-5 pin 3 will be connected to various outputs of the BCD to 1 of 10 decoder IC 180, except in mode COUNT A in which no decimal point is displayed. In mode FREQUENCY A and resolution 100 Hz, pins 3 and 4 are interconnected. When the "enable" pulse for digit number 4 arrives at output 4 of IC 180, it is also fed to the DP input of IC 181. A "decimal point pulse" is then fed from IC 181:10 to the decimal point 4 in the display.

7. Power supply

7.1. General

Refer to circuit diagram fig. XIII-6.

The power supply operates from 115 V AC or 230 V AC 50 to 400 Hz *or* from the internal battery PM 9673 *or* from an external battery with an output voltage of 12 to 28 V. It provides five stabilised and overload-protected voltages of +120 V, +12 V, +5 V, —5 V and —50 V.
The power supply may be divided into the *power input circuit* mainly consisting of the mains transformer T 101 and rectifier GR 167, the *over-voltage protection circuit* mainly consisting of thyristors TS 150, TS 151 and zener diode GR 160, the *voltage regulation circuit* mainly consisting of voltage regulator IC 150, thyristor TS 154, the*DC-to-DC converter* mainly consisting of primary side of transformer T 102, driver TS 152 and switch TS 153.

7.2. Power input circuit

When the power supply operates from the *mains*, the 115 V AC or 230 V AC is transformed to 20 V AC by transformer T 101, rectified in the diode-bridge GR 167, filtered by C 152 and C 161 and fed to the power supply circuits via switch SK 121 and SK 102.
When the power supply operates from an *external battery* the current to the power supply circuits is fed from BU 21 at the rear panel via protecting diode GR 164 and switches SK 121 and SK 102.
When the internal battery is used the current is fed from pin 8 of BU 105 via SK 121 and SK 102 to the power supply circuits.

7.3. Over-voltage protection

The over-voltage protection circuit consists mainly of thyristors TS 150, TS 151 and zener diode GR 160.
The anode of GR 160 is connected to the +5 V output from the power supply. If this voltage increases to 5.6 V . . . 5.8 V, the zener diode GR 160 will start to conduct and a current will flow through resistor R 1121. The voltage drop across R 1121 is fed to the gate of thyristor TS 151 via resistor R 1120. The anode is connected to the +5 V output voltage via resistor R 1118.
The thyristor will switch on and a voltage drop arises across resistor R 1122. This voltage is fed to the gate of thyristor TS 150, whose anode is connected to the d.c. input voltage. The thyristor will switch on and blow fuse VL 150, or, if the counter is operating in the internal battery mode, fuse VL 1 in the battery unit PM 9673. The capacitor across the gate and cathode of thyristor TS 151 prevents transients from the mains to blow fuse VL 150 accidentally.



Fig. VIII-6. Timing diagram of display scanning principle and blanking pulse generation

7.4. DC toDC converter

Refer to diagrams fig. VIII-7.

The DC to DC converter is basically a blocking oscillator consisting mainly of switch transistor TS 153 and terminals 4—9 of the transformer T 102. When switch SK 102 is set to position ON, the DC voltage from the *power input circuit* is fed to the transistor TS 155 which works as a constant current source of approximately 1 mA (I_1).
The current I_1 will cause switch transistor TS 153 to start conducting and the linearly increasing current I_2 to flow.
This current I_2 will cause a voltage across terminals 3—8 of the transformer and the current I_3 will start to flow.
This will cause drive transistor TS 152 to saturate switch transistor TS 153. When the transistor no longer can saturate, current I_3 will stop to increase and the induced voltage at terminal 3 of transformer T 102 will disappear.
This will cause TS 153 to switch off and the collector voltage to rise to the same level as the supply voltage. At this moment the magnetic flux will discharge through the secondary windings of T 102 and diodes GR 155—159.

7.5. Output voltage regulation circuit

The output voltage regulation circuit consists mainly of voltage regulator IC 150 and thyristor TS 154.
The purpose of the thyristor TS 154 is to switch off the drive transistor TS 152 in order to regulate the output voltage. The switching moment of thyristor TS 154 is determined by a voltage at the gate of the thyristor which is the sum of a DC regulation voltage from terminal 10 of IC 150 and a sawtooth voltage caused by the emitter current of TS 153 through resistor R 1114//R 1115.
The voltage regulator IC 150 is fed at terminal 12 with the supply voltage and at terminal 7 with a negative voltage, via GR 161, from winding 3—8 of transformer T 102.
IC 150 contains a differential amplifier with inputs at terminals 4 and 5.
The input at terminal 5 is grounded via R 1104 and the input at terminal 4 is connected to a voltage divider that consists of the reference output at terminal 6 and the negative voltage from winding 3—8 of transformer T 102 at terminal 7.
The differential amplifier is in balance when the voltage at terminal 7 is —5 V. When the supply voltage across windings 4—9 of transformer T 102 increases, the voltage at the differential amplifier at terminal 7 of IC 150 will go more negative, the DC regulation voltage at terminal 10 of IC 150 will go positive and turn on thyristor TS 154. This will connect the base of driver transistor to the ground and cause switch transistor TS 153 to switch off. The stored magnetic flux will then discharge in the secondary windings of T 102 and diodes GR 155—GR 159.



Fig. VIII-7. Current paths in DC-to-DC converter

IX. PERFORMANCE CHECK

1. Survey of check points

3. FREQUENCY AND PERIOD A
4. RESET
5. DISPLAY TIME
6. MEMORY
7. PERIOD A
8. COUNT A START/STOP
9. RATIO A/C
10. RATIO B/C PM 6613
11. RATIO B/C PM 6614 and PM 6615
12. INPUT A. Low frequency filter and trigger mode selectors
13. FREQUENCY A. Frequency response, sensitivity and sine wave trigger selector
14. INPUT A. Low frequency filter and square wave trigger selectors
15. INPUT A. Attenuator
16. INPUT B. Frequency response, sensitivity and automatic gain control
17. INPUT C. Frequency range and sensitivity
18. 10 MHz OUT
19. Temperature compensated crystal oscillator PM 9678
20. Oven enclosed oscillator PM 9679 and PM 9690
21. Standard oscillator PM 9677

2. Test equipment and accessories

Test-point	*Instrument or device*	*Required data*	*Recommended model*
9, 10, 11	LF generator	Frequency: 10 MHz Amplitude: 0.5 V Signal mode: sine wave	Philips PM 5145
9, 10	T-piece	BNC	Philips PM 9067
11	HF generator	Frequency: 50 MHz Amplitude: 10 mV Signal mode: sine wave	Wavetek 2001
13	LF generator	Frequency: 10 Hz Amplitude: 20 mV Signal mode: sine wave	Philips PM 5145
13	HF generator	Frequency: 1—80 MHz Amplitude: 20 mV Signal mode: sine wave	Wavetek 2001
14	LF generator	Frequency: 100 kHz—5 MHz Amplitude: 400 mV Signal mode: sine wave	Philips PM 5145
14	HF oscillator	Frequency: 80 MHz Amplitude: 3 V Signal mode: sine wave	General Radio 1215
14	Pulse generator	Frequency: 5 MHz Duration: 6 ns Amplitude: 300 mV	Philips PM 5715
14	Attenuator	20 dB	Texscan FP50 BNC Outline A
15	LF generator	Frequency: 1 kHz Amplitude: 400 mV Signal mode: sine wave	Philips PM 5145
15	HF generator	Frequency: 80 MHz Amplitude: 200 mV Signal mode: sine wave	Wavetek 2001
16	Sweep generator	Sweep width: 1000 MHz Amplitude: —4 to + 10 dBm Signal mode: sweep and CW mode	Wavetek 2001
16	DC voltmeter	± 5 V dc	Philips PM 2412
17	HF generator	Frequency: 10 MHz Amplitude: 50 mV Signal mode: sine wave	Wavetek 2001
17	LF generator	Frequency: 1 kHz Amplitude: 0.5 V Signal mode: sine wave	Philips PM 5145
18	Oscilloscope	Bandwidth: 50 MHz	Philips PM 3250
18	Probe to BNC conversion bush	5 kohm, 100 × attenuation	Included in Philips PM 9343
19	Reference oscillator	Accuracy 1×10^{-7}	Philips PM 9680*, PM 9681* and PM 9690*
20	Reference oscillator	Accuracy 3×10^{-8}	Philips PM 9680*, PM 9681* and PM 9690*
20	Reference oscillator	Accuracy 1×10^{-9}	HP 105*
20	Sampling oscilloscope	Bandwidth > 1 GHz	Philips PM 3400
21	Reference oscillator	Accuracy 1×10^{-6}	Philips PM 9680*, PM 9681* and PM 9690*

* To be checked against a frequency standard such as Droitwich or HBG.

3. FREQUENCY and PERIOD A

3.1. Set the controls of the counter:

DISPLAY TIME ❶	mid position
CHECK ❼ ❿	depressed
FUNCTION ⓫	100 Hz

3.2. Rotate FUNCTION selector ⓫ and check displayed value and GATE lamp ❷.

Function selector	*Display read-out ± 1 digit*	*Gate lamp is on during:*
100 Hz	10.0000	100 ms
10 Hz	10.00000	100 ms
1 Hz	10000.000	1 s
0.1 Hz	10000.0000	10 s
$n = 1$	0.1	—
$n = 10^2$	0.100	100 ms
$n = 10^4$	0.10000	100 ms

4. RESET

4.1. Set the controls of the counter:

FUNCTION ⓫	1 Hz
CHECK ❼ ❿	depressed
DISPLAY TIME ❶	mid position

4.2. Check that display read-out is 10000.000 ± 1 digit and that GATE lamp ❷ is turned on during one second.

4.3. Pull DISPLAY TIME switch ❶ and depress RESET push-button ⓭. Check that GATE lamp ❷ is turned off and that display read-out is 0.000.

4.4. Release RESET push-button ⓭ and check that display read-out is 10000.000 ± 1 digit and that GATE lamp ❷ is turned on once during one second.

5. DISPLAY TIME

5.1. Set the controls of the counter:

FUNCTION ⓫	100 Hz
CHECK ❼ ❿	depressed
MEMORY ⓬	released
DISPLAY TIME ❶	depressed, position ON

5.2. Check that display read-out is 10.0000 ± 1 digit and that flashing frequency of the GATE lamp ❷ is approximately five flashes every second.

5.3. Rotate DISPLAY TIME potentiometer ❶ slowly from position ON to position MAX and observe how flashing frequency of the GATE lamp ❷ decreases to approximately one flash every five seconds in position MAX.

5.4. Pull DISPLAY TIME switch ❶ and check that display shows 10.0000 ± 1 digits and that GATE lamp ❷ is turned off.

6. MEMORY

6.1. Set the controls of the counter:

FUNCTION ⓫	0.1 Hz
CHECK ❼ ❿	depressed
DISPLAY TIME ❶	mid position
MEMORY ⓬	depressed

6.2. Observe the display and check that the counter is counting during 10 seconds and shows 10000.0000 ± 1 digit during approximately one second.

6.3. Observe the GATE lamp ❷ and check that it is turned on during the counting time (10s) and turned off during the time the result is presented at the display (1s).

6.4. Release MEMORY push-button ⓬ and check that the display shows 10000.0000 ± 1 digit permanently.

7. PERIOD A

Test set up

7.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
FUNCTION ⓫	PERIOD A, $n = 10^4$
TRIGGER SELECTOR ❼	depressed
MEMORY ⓬	released
SENSITIVITY ❸	fully CW

7.2. Check that display read-out is 0.10000 ± 1 digit.

8. COUNT A START/STOP

Test set up

8.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
FUNCTION ⓫	COUNT A
MEMORY ⓬	released (position STOP)
SENSITIVITY ❸	pulled
TRIGGER SELECTOR ❼	depressed

8.2. Depress push-button MEMORY ⓬ (position START) and check at the display that the counter is adding the input pulses.

8.3. Release push-button MEMORY ⓬ (position STOP) and check at the display that the counter stops adding. The display is now showing the amount of pulses counted in the time interval between depressing and releasing the push-button MEMORY ⓬ (START/STOP).

8.4. Depress push-button RESET ⓭ and check that display shows zero.

8.5. Pull switch DISPLAY TIME ❶ and repeat steps 8.2 to 8.4.

9. RATIO A/C

Test set up



9.1. Set the controls of the counter:

FUNCTION ⓫	RATIO n = 10^2
DISPLAY TIME ❶	position ON
TRIGGER SELECTOR ❼	depressed
SENSITIVITY ❸	pulled

9.2. Set the controls of the low frequency generator.

Frequency:	10 MHz
Amplitude:	0.5 V
Signal mode:	Sine wave

9.3. Check that display read-out is 1.00 ± 1 digit.

9.4. Set FUNCTION selector ⓫ to position n = 10^4. Check that display read-out is 1.0000 ± 1 digit.

---

10. RATIO B/C PM 6613. Not applicable for PM 6611

Test set up



10.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
CHANNEL B ❺	depressed
FUNCTION ⓫	RATIO n = 10^2

10.2. Set the controls of the low frequency generator.

Frequency:	10 MHz
Signal mode:	sine wave
Amplitude:	0.5 V

10.3. Check that display read-out is 1.00 ± 1 digit. Set FUNCTION selector ⓫ to position RATIO n = 10^4 and check that display read-out is 1.0000 ± 1 digit.

---

11. RATIO B/C PM 6614 and PM 6615. Not applicable for PM 6611

Test set up



11.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
CHANNEL B ❺	depressed
FUNCTION ⓫	RATIO n = 10^2

11.2. Set the controls of the high frequency generator:

Frequency:	50 MHz
Signal mode:	sine wave
Amplitude:	10 mV

11.3. Set the controls of the low frequency generator:

Frequency:	10 MHz
Signal mode:	sine wave
Amplitude:	0.5 V

11.4. Check that display read-out is approx. 5 with two decimals.

11.5. Set FUNCTION selector ⓫ to position RATIO n = 10^4 and check that display read-out is approx. 5 with four decimals.

12. INPUT A with low frequency filter, trigger mode selectors and attenuator

Test set up

12.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
FUNCTION ⓫	1 Hz
TRIGGER SELECTOR ❼	depressed
SENSITIVITY ❸	fully CW, depressed

12.2. Check that display read-out is 10000.000. Depress LOW FREQUENCY FILTER, push-button ⓾ and check that display read-out is 0.000.

12.3. Depress TRIGGER SELECTOR push-button ❼ and set FUNCTION SELECTOR rotary switch ⓫ to position 100 Hz. Check that display read-out is 10.0000.

12.4. Turn SENSITIVITY potentiometer ❸ slowly counter clockwise until display shows zero. Stop. Turn the potentiometer slowly clockwise until display shows 10.0000. Stop.

12.5. Depress TRIGGER SELECTOR push-button ❻ and check that display shows zero.

12.6. Depress TRIGGER SELECTOR push-button ❹ and check that display shows zero.

12.7. Pull SENSITIVITY switch ❸ and check that display shows 10.0000.

12.8. Depress TRIGGER SELECTOR push-button ❻ and check that display shows 10.0000.

13. FREQUENCY A. Frequency response, sensitivity and sine wave trigger selector

Test set up



13.1. Set the controls of the counter:

FUNCTION ⓫	FREQUENCY 1 Hz
DISPLAY TIME ❶	Position ON
TRIGGER SELECTOR ❼	depressed
SENSITIVITY ❸	pulled, fully clockwise

13.2. Set the controls of the low frequency generator:

Amplitude:	20 mV
Frequency:	10 Hz
Signal mode:	sine wave

13.3. Check that display read-out is 0.010.

13.4. Slowly decrease the amplitude of the signal from the low frequency generator until display read-out becomes wrong. Stop. Slowly increase the amplitude just until dsplay read-out becomes correct. Stop.

13.5. Check by means of an oscilloscope that the amplitude is less than 56 $mV_{p\text{-}p}$.

13.6. Set the frequency of the low frequency generator to 20 Hz and the amplitude to 20 mV.

13.7. Check that display read-out is 0.020 and repeat step 13.4.

13.8. Check by means of an oscilloscope that the amplitude is less than 28 $mV_{p\text{-}p}$.

13.9. Set the frequency of the low frequency generator to 1 kHz and the amplitude to 20 mV.

13.10. Check that display read-out is 1.000 and repeat step 13.4.

13.11. Check by means of an oscilloscope that the amplitude is less than 28 $mV_{p\text{-}p}$.

Change test set up



13.12. Set the controls of the high frequency generator:

Frequency:	10 MHz
Amplitude:	20 mV
Signal mode:	sine wave

13.13. Check that display read-out is 10000.000 and repeat step 13.4.

13.14. Check by means of an oscilloscope that the amplitude is less than 28 $mV_{p\text{-}p}$.

13.15. Set the frequency of the high frequency generator to 80 MHz and the amplitude to 20 mV.

13.16. Check that display read-out is 80000.000 and repeat step 13.4.

13.17. Check by means of an oscilloscope that the amplitude is less than 28 $mV_{p\text{-}p}$.

14. INPUT A. Low frequency filter and square wave trigger selectors

Test set up



14.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
FUNCTION ⓫	FREQUENCY 1 Hz
LOW FREQUENCY FILTER ⓾	depressed
SENSITIVITY ❸	pulled, fully clockwise

14.2. Set the controls of the low frequency generator:

Frequency:	100 kHz
Amplitude:	20 mV
Signal mode:	sine wave

14.3. Check that display read-out is 100.000.

14.4. Slowly decrease the amplitude of the signal from the low frequency generator until display read-out becomes wrong. Stop. Slowly increase the amplitude until display read-out becomes correct. Stop.

14.5. Check by means of an oscilloscope that the amplitude is less than 28 mV_{p-p}.

14.6. Set the frequency of the low frequency generator to 500 kHz and the amplitude to 50 mV.

14.7. Check that the display read-out is 500.000 and repeat step 14.4.

14.8. Check by means of an oscilloscope that the amplitude is 56 to 70 mV_{p-p}.

14.9. Set the frequency of the low frequency generator to 5 MHz and the amplitude to 0.1 V.
Check that the display shows wrong read-out.

14.10. Increase the amplitude to 0.39 V and check that the display still shows wrong read-out.

Change test set up



14.11. Set the frequency of the high frequency generator to 80 MHz and the amplitude to 1 V.
Check that the display shows wrong read-out.

14.12. Increase the amplitude to 2.4 V and check that the display still shows wrong read-out.

Change test set up



14.13. Depress TRIGGER SELECTOR ❻

14.14. Set the controls of the pulse generator:

Frequency:	5 MHz
Amplitude:	20 mV
Duration:	6 ns

14.15. Check that the display read-out is 5000.000 and repeat step 14.4.

14.16. Check by means of an oscilloscope that the amplitude is less than 56 mV_{p-p}.

14.17. Depress TRIGGER SELECTOR ❹ and repeat steps 14.14 to 14.16.

15. INPUT A. Attenuator

Test set up



15.1. Set the controls of the counter:

DISPLAY TIME ❶	position ON
FUNCTION ⓫	1 Hz
TRIGGER SELECTOR ❼	depressed
SENSITIVITY ❸	pulled, fully clockwise

15.2. Set the controls of the low frequency generator:

Amplitude:	200 mV
Frequency:	1 kHz
Mode:	sine wave

15.3. Check that display read-out is 1.000.

15.4. Turn SENSITIVITY potentiometer ❸ from fully clockwise to fully counter clockwise and check that display read-out is 1.000.

15.5. Slowly decrease the amplitude of the sine wave signal until the display shows wrong read-out. Stop. Slowly increase the amplitude until display read-out becomes 1.000. Stop.

15.6. Check the amplitude of the sine wave signal. Typical value is 150 mV.

Change test set up



15.7. Set the controls of the high frequency generator:

Amplitude:	200 mV
Frequency:	80 MHz
Signal mode:	sine wave

15.8. Check that display read-out is 80000.000.

15.9. Repeat steps 15.5 and 15.6.

16. INPUT B. Frequency response, sensitivity and automatic gain control. Not applicable for PM 6611.

Test set up



16.1. Set the controls of the counter:

CHANNEL B ❺	depressed
FUNCTION ⓫	FREQUENCY 100 Hz
DISPLAY TIME ❶	position ON

16.2. Set the sweep generator to sweep width 250 MHz for PM 6613, 520 MHz for PM 6614 and 1000 MHz for PM 6615. Set the amplitude to 10 mV and let the sweep generator operate in slow sweep speed mode.

16.3. Observe the display and start the sweep generator. Check that the counter is counting the whole frequency range steadily. If the PM 6615 is not counting properly increase the amplitude to 15 mV.

16.4. Set the frequency of the sweep generator to 5 MHz for PM 6613 and 50 MHz for PM 6614 and PM 6615. Set the amplitude to 10 mV.
The sweep generator should operate in the CW mode.

16.5. Check that display read out is 5.0000 for PM 6613 and 50.0000 for PM 6614 and PM 6615.

16.6. Slowly decrease the amplitude of the signal until the display shows zero. Stop. Slowly increase the amplitude until display shows correct read-out. Stop. Check that the amplitude is < 10 mV.

16.7. Set the sweep generator to 250 MHz for PM 6613, 520 MHz for PM 6614 and 1000 MHz for PM 6615. Set the amplitude to 10 mV.
The sweep generator should operate in the CW mode.

16.8. Check that display read-out is 250.0000 for PM 6613, 520.0000 for PM 6614 and 1000.0000 for PM 6615.

16.9. Repeat step 16.6.

16.10. Set the frequency of the sweep generator to 150 MHz and the amplitude to —40 dBm.
The sweep generator should operate in the CW mode.

16.11. Connect the dc voltmeter to terminal 6 of IC 204 and check the A.G.C. dc voltage according to table below:

Set amplitude (dBm)	*Measured amplitude (V)*
—3.2	—2.8 to —3.1
—2.0	—0.2 to —0.8
+0.4	+0.6 to +0.9
+1.2	+1.2 to +1.8
+2.0	+1.9 to +2.5
+2.6	+2.5 to +3.2

---

17. INPUT C. Frequency range and sensitivity

Test set up



17.1. Set the controls of the counter:

FUNCTION ⓫	RATIO n = 10^2
SENSITIVITY ❸	pulled, fully clockwise
DISPLAY TIME ❶	position ON
TRIGGER SELECTOR ❼	depressed

17.2. Set the controls of the high frequency generator:

Frequency:	10 MHz
Amplitude:	50 mV
Mode:	sine wave

17.3. Set the controls of the low frequency generator:

Frequency:	1 kHz
Amplitude:	500 mV
Mode:	sine wave

17.4. Check that display read-out is $\frac{fA}{fC}$ with two decimals i.e. $\frac{1\ kHz}{10\ MHz} = 10000.00$.

17.5. Slowly decrease the amplitude of signal at input C until display shows wrong read-out. Stop. Slowly increase the amplitude until display shows correct read-out. Stop.

17.6. Check that the amplitude of the signal at input C is less than 500 mV. Typical value is 450 mV.

17.7. Set the signal at input C to 1 MHz and 600 mV. Check that display shows $\frac{fA}{fC}$ with two decimals i.e. $\frac{10\ MHz}{1\ MHz} = 10.00$.

17.8. Repeat step 17.5 and check that the amplitude of the signal at input C is less than 500 mV. Typical value is 275 mV.

17.9. Set the frequency of the signal at input C to 10 MHz and the amplitude to 600 mV. Check that display shows $\frac{fA}{fC}$ with two decimals i.e. $\frac{10\ MHz}{10\ MHz} = 1.00$.

17.10. Repeat step 17.5 and check that the amplitude of the signal at input C is less than 500 mV. Typical value is 250 mV.

18. 10 MHz OUT

Test set up



18.1. Set the sampling oscilloscope to 10 mV/cm and 20 ns/cm.

18.2. Check that oscilloscope displays a signal with waveform and amplitude similar to figure IX-1.



Figure IX-1. 10 MHz out.

---

19. Temperature compensated crystal oscillator PM 9678

Test set up

19.1. This check requires a frequency standard having an accuracy of 1×10^{-7}.

The oven enclosed oscillators Philips PM 9680, PM 9681 and PM 9690 meet this requirement.
The check should preferably be made at an ambient temperature of +25° C.

19.2. Set the controls of the counter:

FUNCTION ⓫ FREQUENCY 0.1 Hz
TRIGGER SELECTOR ❼ depressed

19.3. Check that the display shows 10000.0000 kHz ±1 Hz.

19.4. For adjustment instruction refer to the separate service manual for the oscillators.

---

20. Oven enclosed oscillator PM 9679 and PM 9690

Test set up



20.1. This check requires a frequency standard having an accuracy of 3×10^{-8} for PM 9679. The oven enclosed oscillators Philips PM 9680, PM 9681 and PM 9690 meet this requirement. For PM 9690 an accuracy of 1×10^{-9} is required. The quartz oscillator HP 105 meets this requirement.

CAUTION. The oscillator must have been operating continuously for at least 72 h before any check is made.

Waveform moves	*Oscillator frequency*
→	too low
←	too high

20.2. Observe the movement of the displayed waveform.

20.3. For adjustment instruction refer to the separate service manual for the oscillators.

---

21. Standard oscillator PM 9677

Test set up



21.1. This check requires a frequency standard having an accuracy of 1×10^{-6}. The oven enclosed oscillators Philips PM 9690, PM 9681 and PM 9690 meet this requirement. The check should preferably be made, at an ambient temperature of +25° C.

21.2. Set the controls of the counter:

FUNCTION ⓫ FREQUENCY 1 Hz
TRIGGER SELECTOR ❼ depressed

21.3. Check that display shows 10000.000 kHz ±10 Hz.

21.4. For adjustment instructions refer to separate service manual for the oscillators.

X. INTERNAL CHECKS AND ADJUSTMENTS

The tolerances mentioned in the following text apply to newly adjusted instruments only. The value may differ from those given in chapter II Technical Data.

Note: Always check the d.c. supply voltage before any adjustments are made!

1. Use figure XIII-2 to identify location of trimmers and check points.

2. Test equipment

Check point	*Instrument*	*Required data*	*Recommended model*
3	Voltmeter	5—150 V d.c.	Philips PM 2412
4 5	Oscilloscope	50 MHz bandwidth	Philips PM 3250
4 5	Probe	Passive 10 MΩ/11 pF	Philips PM 9336
4	LF generator	Frequency 10 kHz Amplitude 10 mV Signal mode sinewave	Philips PM 5145
5	Pulse generator	Frequency 10 kHz Amplitude 1 V Duty factor 0.5	Philips PM 5715 or PM 5705

3. D.C. voltages

3.1. Connect voltmeter to jumper connector BU104 and check the d.c. voltages according to table below.

Testpoint	*Measured voltage*
+120	+115 to 130 V
+5.2	+4.8 to 5.2 V
+12	+11.5 to 13.0 V
—5.2	—5.2 to —6.0 V
—50	—50 to —60 V

4. D.C. balance channel A

Test set up



4.1. Set the controls of the counter:

TRIGGER SELECTOR ❼ depressed
SENSITIVITY ❸ pulled, fully clockwise

4.2. Set the controls of the low-frequency generator:

Frequency : 1 kHz
Amplitude : 10 mV
Signal mode: Sine wave

4.3. Connect the oscilloscope via a well-adjusted 10 MΩ/11 pF probe to junction L101/R132.
Adjust R127 until displayed waveform has duty factor 0.5.

5. Frequency compensation channel A



5.1. Set the controls of the counter:

TRIGGER SELECTOR ❼ depressed

5.2. Set the controls of the pulse generator:

Frequency : 10 kHz
Amplitude : 1 V
Duty factor: 0.5

5.3. Connect the oscilloscope to L103 via a well-adjusted 10 MΩ/11 pF probe.
Adjust C102 to best square-wave symmetry of displayed waveform.

XI. OSCILLATORS PM 9677, PM 9678, PM 9679 and PM 9690



PM 9677
9446 096 770.1



PM 9678
9446 096 780.1

PM 9679
9446 096 790.1

PM 9690
9446 096 900.1

1. General

The oscillators are made as plug-in cards and have a nominal frequency of 10 MHz.

2. Technical data

2.1. Electrical	*PM 9677*	*PM 9678*	*PM 9679*	*PM 9690*
Nominal frequency, MHz	10.000 000	10.000 000	10.000 000	10.000 000
Trimming range, Hz	$> \pm 200$	$> \pm 20$	+20*) —30	+3*) —7
Output voltage, mV (into 1 kohm)	> 300	> 100	> 150	> 50
Supply voltage, V	+ 12	+ 12	+ 11.5 to 28 (from unregulated power supply)	+ 11.5 to 28 (from unregulated power supply)
Power consumption (+25°C)				
Continuous operation	< 100 mW	< 200 mW	< 100 mA	< 125 mA
Stand by	none	none	< 100 mA	< 125 mA
Warm up	none	none	< 400 mA	< 400 mA
Stability against:				
Ageing	$< 5\times10^{-7}$/month	$< 1\times10^{-7}$/month**)	$< 1\times10^{-7}$/month	$< 1.5\times10^{-9}$/24 h (after 72 hours of continuous operation)
Temperature 0 . . . 50°C (ref. to +25°C)	$< 1\times10^{-5}$	$< 1\times10^{-6}$	$< 1\times10^{-7}$	$< 3\times10^{-8}$
Line voltage ± 10 %	$< 1\times10^{-8}$	$< 1\times10^{-9}$	$< 1\times10^{-9}$	$< 5\times10^{-10}$
Change of measuring mode and change between line, ext. and int. battery	$< 3\times10^{-7}$	$< 5\times10^{-8}$	$< 1\times10^{-8}$	$<3\times10^{-9}$
Warm up time (to reach 1×10^{-7})			< 10 min	< 15 min

2.2. Environmental				
Temperature				
Storage, °C	—40 to +70	—40 to +70	—40 to +70	—40 to +70
Operating, °C	0 to +50	0 to +50	0 to +50	0 to +50
Altitude				
Storage, m	15000	15000	15000	15000
Operating, m	5000	5000	5000	5000
Humidity at 50°C	10—90 % RH (26° dew point)	10—90 % RH (26° dew point)	10—90 % RH (26° dew point)	10—90 % (26° dew point)
Shock	Meets the requirement of the IEC Eb recommendations } all oscillators			
Vibration	Meets the requirement of the IEC 68F recommendations } all oscillators			

2.3. Mechanical				
Dimensions, mm	93×50×20	93×50×15	100×52×35	100×52×35
Weight, g	50	25	100	100

*) The indicated values regard only the fine trimming range. A coarse trimmer is available on the PM 9679 and PM 9690 to adjust for an ageing of more than 10 years.

**) Trimming range will cover at least 10 years of operation since the ageing will decrease substantially after the first 6 months.

3. Frequency adjustment PM 9677

3.1. This adjustment requires a reference oscillator having an accuracy of $\leq 1 \times 10^{-6}$.
The oven enclosed PHILIPS oscillators PM 9680*, PM 9681* and PM 9690* meet this requirement.
The adjustment should preferably be made at an ambient temperature of +25°C.
3.2. Remove the bottom cover of the counter.
3.3. Connect the reference signal available at socket 10 MHz OUT of the external counter to INPUT A of the counter to be adjusted.
3.4. Set the controls of the counter to be adjusted:
FUNCTION SELECTOR ⓫: FREQUENCY 1 Hz (1s)
TRIGGER SELECTOR ❼ : depressed
3.5. Adjust trimming capacitor C 1 to 10000.000 kHz plus or minus 10 Hz.

4. Frequency adjustment PM 9678

4.1. This adjustment requires a reference oscillator having an accuracy of $\leq 1 \times 10^{-7}$.
The oven enclosed PHILIPS oscillator PM 9680*, PM 9681* and PM 9690* meet this requirement.
The adjustment should preferably be made at an ambient temperature of +25°C.
4.2. Remove the bottom cover of the counter.
4.3. Connect the reference signal available at socket 10 MHz OUT of the external counter to INPUT A of the counter to be adjusted.
4.4. Set the controls of the counter to be adjusted:
FUNCTION SELECTOR ⓫: FREQUENCY 1 Hz (1s)
TRIGGER SELECTOR ❼ : depressed.
4.5. Adjust trimming capacitor C 1 to 10000.000 kHz plus or minus 1 Hz.
4.6. Set FUNCTION SELECTOR ⓫ to position 0.1 Hz (10s) and check that display read-out is the same as before. If not, adjust C 1 slightly to correct frequency.

5. Frequency adjustment PM 9679

5.1. This adjustment requires a reference oscillator having an accuracy of $\leq 3 \times 10^{-8}$.
The oven enclosed PHILIPS oscillators PM 9680*, PM 9681* and PM 9690* meet this requirement.
The adjustment should preferably be made at an ambient temperature of 25°C and the oscillator must have been operating continuously 72 h before any adjustment is made.
5.2. Remove the bottom cover of the counter.
5.3. Connect the reference signal available at socket 10 MHz OUT of the external counter to socket EXT. TRIGG of oscilloscope PHILIPS PM 3250 or PM 3400.
5.4. Connect the oscillator signal available at socket 10 MHz OUT of the counter to be adjusted to INPUT A of the oscilloscope.
5.5. Set oscilloscope to 100 ns/div and adjust trimming potentiometer R 208 until waveform moves with a velocity of maximum 1 div./3 s (0.3 Hz).
If the adjustment range of R 208 is too narrow perform the following steps 5.6 to 5.12.
5.6. Set trimming potentiometer R 208 to fully clockwise position.
5.7. Remove the two screws fixing the oscillator's text plate to the box.
5.8. Remove the small plastic cylinder beneath the text plate using a pair of tweezers.
5.9. Connect an external counter to socket 10 MHz OUT at the rear panel of the counter to be adjusted.
5.10. Adjust trimming capacitor C 108 until the display read out of the external counter is 10000020 Hz.
5.11. Refit the plastic cylinder and the text plate.
5.12. Perform steps 5.3 to 5.5.

6. Frequency adjustment PM 9690

6.1. This adjustment requires a reference frequency having an accuracy of $\leq 1 \times 10^{-9}$.
Hewlett-Packard quartz frequency standard HP 105* meets this requirement.
The adjustment should preferably be made at an ambient temperature of 25°C and the oscillator must have been operating continuously 72 h before any adjustment is made.
6.2. Remove the bottom cover of the counter.
6.3. Connect any of the three reference signals available at sockets 5 MHz, 1 MHz and 100 kHz of the HP 105 to socket EXT. TRIGG of oscilloscope PHILIPS PM 3250 or PM 3400.
6.4. Connect the oscillator signal available at socket 10 MHz OUT of the counter to be adjusted to INPUT A of the oscilloscope.
6.5. Set oscilloscope to 100 ns/div and adjust trimming potentiometer R 208 until waveform moves with a velocity of maximum 1 div/10 s (0.1 Hz).
If the adjustment range of R 208 is too narrow perform the following steps 6.6 to 6.12.
6.6. Set trimming potentiometer R 208 to fully clockwise position.
6.7. Remove the two screws fixing the oscillator's text plate to the box.
6.8. Remove the small plastic cylinder beneath the text plate using a pair of tweezers.
6.9. Connect an external counter to socket 10 MHz OUT at the rear panel of the counter to be adjusted.
6.10. Adjust trimming capacitor C 108 until the display read out of the external counter is 10000003 Hz.
6.11. Refit the plastic cylinder and the text plate.
6.12. Perform steps 6.3 to 6.5.

7. Repair of oscillator PM 9679 and PM 9690

7.1. Repair of these oscillators may not be carried out by the local service organisations. In case of breakdown the complete sealed osclllator box has to be sent to the factory for repair.

Factory address:

PHILIPS ELEKTRONIKINDUSTRIER AB
INDUSTRIAL OPERATIONS
FACK
S-175 20 JÄRFÄLLA
SWEDEN

8. Pin configuration



*To be checked against a frequency standard such as Droitwich or HBG.

9. Circuit diagram, component lay-out and spare parts list PM 9677



	RESISTORS		
4822 110 63161	100K	5	CR25 R1
4822 110 63116	2•2K	5	CR25 R2
4822 110 63107	1K	5	CR25 R3
4822 110 63107	1K	5	CR25 R4
4822 110 63107	1K	5	CR25 R5
4822 110 63107	1K	5	CR25 R6
	CAPACITORS		
5322 125 54029	2=18P		300 C1
4822 122 31063	22P	2	100 C2
4822 122 31072	47P	2	100 C3
4822 122 31076	68P	2	100 C4
5322 122 34041	10N	=20•50	100 C5
5322 122 34041	10N	=20•50	100 C6
5322 122 34041	10N	=20•50	100 C7
5322 124 14036	15M	=10•50	16 C8
	SEMI CONDUCTORS		
5322 130 44418	BF 256 A		TS1
5322 130 44418	BF 256 A		TS2
5322 130 30766	BZX79=C6V2		GR1
	MISCELLANEOUS		
5322 242 74036	CRYSTAL 10MHZ		
5322 267 64031	CONNECTOR		BU1

Spare parts PM 9677

Figure XI-1. Component lay-out PM 9677



Figure XI-2. Circuit diagram PM 9677

10. Circuit diagram, component lay-out and spare parts list PM 9678



Figure XI-3. Component lay-out PM 9678



Figure XI-4. Circuit diagram PM 9678

ORDERING NUMBER

4822 110 63098	470 Ω 5 %		R 1
5322 125 50057	5–65 P	100 V	C 1
5322 124 14036	15 M −10 + 50 %	16 V	C 2
5322 267 64031	Connector		BU 1
5322 216 94047	Crystal 10 MHz		

XII. REPLACING PARTS

1. Push-button switches

1.1. If necessary loosen unit U2.

1.2. Loosen switch by bending the four tags securing the switch to the switch bracket.



Figure XII-1. Replacing push-button switch.

1.3. Crush the switch by means of a pair of cutting pliers.

1.4. Unsolder the contact pins from the circuit board one by one. Use a sucking device to remove all tin solder from the contact holes in the circuit board before attaching the new switch.

2. Text plate and front rim

2.1. Remove the knobs for DISPLAY TIME, SENSITIVITY and function selector.

2.2. Put a screw driver between the front rim and the front frame at points A as shown in figure XII-2.



Figure XII-2. Removing the front rim.

2.3. Pry gently until front rim comes off.

2.4. Remove the text plate.

3. Handle

3.1. Remove the two plastic caps using a tiny screw driver or a pair of pliers.

3.2. Unscrew the two screws and pull out handle.

3.3. Before assambling grease, the tooth washer screwhole and teeth of the handle *very slightly* with vaseline.

4. Power supply

When replacing parts in the power supply, in particular IC150, always check the +5,0 V supply.

Proceed as follows:

4.1. Connect a voltmeter to BU107 pin +5,2 V and check that the voltage is 4.8—5.2 V
If the measured voltage does not reach 4.8—5.2 V unsolder R 1103 and select a resistor value that gives the desired voltage. The value of this resistor may be 1 kΩ to 33 kΩ. Typical value is 8 kΩ.

4.2. Check the d.c. voltages, refer to chapter X section 3.

XIII. SPARE PARTS, FAULTFINDING, TESTPOINTS AND CIRCUIT DIAGRAMS

UNIT U1 (all models)
FIXED RESISTORS

Ordering number	Ohm	Tol.(%)	Type	Item
5322 116 54408	909K	1	MR30	R101
4822 110 63165	150K	5	CR25	R102
4822 110 63076	68	5	PR37	R103
4822 110 63072	47	5	CR25	R104
4822 110 63094	330	5	CR25	R106
4822 110 63098	470	5	CR25	R106
4822 110 63087	180	5	CR25	R109
4822 110 63116	2,2K	5	CR25	R110
4822 110 63072	47	5	CR25	R111
4822 110 63141	18K	5	CR25	R112
4822 110 63105	820	5	CR25	R113
4822 110 63105	820	5	CR25	R114
4822 110 63072	47	5	CR25	R115
4822 110 63072	47	5	CR25	R116
4822 110 63072	47	5	CR25	R117
4822 110 63105	820	5	CR25	R118
4822 110 63105	820	5	CR25	R119
4822 110 63081	100	5	CR25	R120
4822 110 63105	820	5	CR25	R121
4822 110 63103	680	5	CR25	R122
4822 110 63098	470	5	CR25	R123
4822 110 63089	220	5	CR25	R124
4822 110 63101	560	5	CR25	R128
4822 110 63067	33	5	CR25	R130
4822 110 63089	220	5	CR25	R131
4822 110 63094	330	5	CR25	R132
4822 110 63098	470	5	CR25	R133
4822 110 63107	1K	5	CR25	R134
4822 110 63063	22	5	CR25	R135
4822 110 63152	47K	5	CR25	R136
4822 110 63138	15K	5	CR25	R138
4822 110 63152	47K	5	CR25	R139
4822 110 63074	56	5	CR25	R140
4822 110 63134	10K	5	CR25	R150
4822 110 63107	1K	5	CR25	R151
4822 110 63089	220	5	CR25	R152
4822 110 63107	1K	5	CR25	R153
4822 110 63107	1K	5	CR25	R154
4822 110 63134	10K	5	CR25	R155
4822 110 63152	47K	5	CR25	R157
4822 110 63107	1K	5	CR25	R158
4822 110 63152	47K	5	CR25	R159
4822 110 63134	10K	5	CR25	R160
4822 110 63134	10K	5	CR25	R161
4822 110 63152	47K	5	CR25	R162
4822 110 63107	1K	5	CR25	R163
4822 110 63152	47K	5	CR25	R164
4822 110 63152	47K	5	CR25	R165
4822 110 63152	47K	5	CR25	R166
4822 110 63152	47K	5	CR25	R167
4822 110 63134	10K	5	CR25	R168
4822 110 63134	10K	5	CR25	R169
4822 110 63134	10K	5	CR25	R170
4822 110 63152	47K	5	CR25	R171
4822 110 63134	10K	5	CR25	R172
4822 110 63138	15K	5	CR25	R180
4822 110 63138	15K	5	CR25	R181
4822 110 63138	15K	5	CR25	R182
4822 110 63138	15K	5	CR25	R183
4822 110 63138	15K	5	CR25	R184
4822 110 63138	15K	5	CR25	R185
4822 110 63138	15K	5	CR25	R186
4822 110 63138	15K	5	CR25	R187
4822 110 63138	15K	5	CR25	R188
4822 110 63098	470	5	CR25	R189
4822 110 63125	4,7K	5	CR25	R190
4822 110 63143	22K	5	CR25	R191
4822 110 63129	6,8K	5	CR25	R192
4822 110 63116	2,2K	5	CR25	R193
4822 110 63116	2,2K	5	CR25	R194
4822 110 63116	2,2K	5	CR25	R195
4822 110 63116	2,2K	5	CR25	R196
4822 110 63116	2,2K	5	CR25	R197
4822 110 63116	2,2K	5	CR25	R198
4822 110 63116	2,2K	5	CR25	R199
5322 116 50524	3,01K	1	MR25	R1101
5322 116 54011	5,62K	1	MR25	R1102
	SELECTED SEE NOTE			R1103 **
4822 110 63107	1K	5	CR25	R1104
4822 110 63121	3,3K	5	CR25	R1105
4822 110 63107	1K	5	CR25	R1106
4822 110 63109	1,2K	5	CR25	R1108
4822 110 63116	2,2K	5	CR25	R1109
4822 110 63169	220K	5	CR25	R1110
4822 110 63089	220	5	CR25	R1111
4822 110 63063	22	5	CR25	R1112
4822 110 63089	220	5	CR25	R1113
4822 110 63032	1,5	5	CR25	R1114
5322 116 54963	0,18	10		R1115
4822 110 63098	470	5	CR25	R1116
4822 110 63089	220	5	CR25	R1117
4822 110 63072	47	5	CR25	R1118
4822 110 63169	220K	5	CR25	R1119
4822 110 63107	1K	5	CR25	R1120
4822 110 63098	470	5	CR25	R1121
4822 110 63081	100	5	CR25	R1122
4822 116 30114	4,7K	NTC	NTC	R1123
4822 113 60084	1	10		R1124
4822 110 63163	120K	5	CR25	R1129
4822 110 63116	2,2K	5	CR25	R1130
4822 110 63134	10K	5	CR25	R1131
4822 110 63134	10K	5	CR25	R1138
4822 110 63134	10K	5	CR25	R1139
4822 110 63134	10K	5	CR25	R1140
4822 110 63116	2,2K	5	CR25	R1141 *
4822 110 63107	1K	5	CR25	R1142 *
4822 110 63152	47K	5	CR25	R1142
4822 110 63134	10K	5	CR25	R1143
4822 110 63185	820K	5	CR25	R1144
4822 110 63134	10K	5	CR25	R1145
4822 110 63134	10K	5	CR25	R1146
4822 110 63134	10K	5	CR25	R1148
4822 110 63152	47K	5	CR25	R1149
4822 110 63134	10K	5	CR25	R1150
4822 110 63214	10M	10	CR25	R1151
4822 110 63143	22K	5	CR25	R1152
4822 110 63152	47K	5	CR25	R1153
4822 110 63152	47K	5	CR25	R1154
4822 110 63152	47K	5	CR25	R1155
4822 110 63096	390	5	CR25	R1156
4822 110 63134	10K	5	CR25	R1158
4822 110 63187	1M	5	CR25	R1159
4822 110 63134	10K	5	CR25	R1160
4822 110 63134	10K	5	CR25	R1161
4822 110 63152	47K	5	CR25	R1162
4822 110 63134	10K	5	CR25	R1163
4822 110 63107	1K	5	CR25	R1164
4822 110 63134	10K	5	CR25	R1165
4822 110 63134	10K	5	CR25	R1166
4822 110 63114	1,8K	5	CR25	R1167
4822 110 63114	1,8K	5	CR25	R1168
4822 110 63114	1,8K	5	CR25	R1169
4822 110 63114	1,8K	5	CR25	R1170
4822 110 63098	470	5	CR25	R1171
4822 110 63098	470	5	CR25	R1172
4822 110 63098	470	5	CR25	R1173
4822 110 63123	3,9K	5	CR25	R1174
4822 110 63116	2,2K	5	CR25	R1175

VARIABLE RESISTORS

Ordering number	Ohm	Tol.(%)	Watt	Item
5322 101 94008	500			R107
5322 101 14069	22K	20	0,5W	R127
5322 101 94007	1M			R1157

*) only instruments with serial prefix SM1

**) refr. to chapter XII section 4

FIXED CAPACITORS

Ordering number	Farad	Tol.(%)	Volts	Item
4822 121 40407	22N	10	630	C101
4822 122 31076	68P	2	100	C103
5322 121 54047	270P	2	500	C104
5322 124 14036	15M	-10+50	16	C105
5322 124 14079	68P	-10+50	6,3	C106
4822 122 31177	470P	10	100	C107
5322 122 34041	10N	-20+50	100	C108
5322 124 14079	68M	-10+50	6,3	C109
4822 122 31081	100P	2	100	C110
5322 122 34041	10N	-20+50	100	C111
5322 122 34041	10N	-20+50	100	C112
5322 124 14079	68P	-10+50	6,3	C117
4822 121 41143	22N	10	250	C120
5322 121 40323	100N	10	100	C121
5322 122 34041	10N	-20+50	100	C122
5322 122 34041	10N	-20+50	100	C123
5322 122 34041	10N	-20+50	100	C124
5322 122 34041	10N	-20+50	100	C125
5322 122 34041	10N	-20+50	100	C126
4822 122 31036	2,2P	2	100	C127
4822 121 41147	33N	10	250	C132
5322 124 14079	68M	-10+50	6,3	C133
5322 124 14079	68M	-10+50	6,3	C134
4822 122 31067	33P	2	100	C135
4822 122 31072	47P	2	100	C137
4822 122 31072	47P	2	100	C138
4822 122 30099	3,3N	10	100	C139
4822 122 30031	820P	10	100	C140*
4822 122 30114	2,2N	10	100	C140
4822 121 40232	220N	10	100	C141
5322 122 34041	10N	-20+50	100	C150
5322 122 34041	10N	-20+50	100	C151
4822 124 20534	680M	-10+50	40	C152
4822 121 41161	150N	10	250	C153
4822 124 20586	150M	-10+50	16	C154
4822 124 20589	220M	-10+50	10	C155
4822 124 20589	220M	-10+50	10	C156
4822 124 20589	220M	-10+50	10	C157
4822 124 20589	220M	-10+50	10	C158
4822 124 20499	22M	-10+50	63	C160
4822 124 20534	680M	-10+50	40	C161
5322 122 34041	10N	-20+50	100	C162
4822 122 31165	330P	10	100	C164
5322 124 14075	1M	-10+50	25	C165
4822 121 40232	220N	10	100	C167
5322 122 34041	10N	-20+50	100	C169
4822 122 31081	100P	2	100	C170
5322 124 14066	10M	-10+50	6,3	C171
5322 121 40323	100N	10	100	C172
5322 122 34041	10N	-20+50	100	C173
5322 122 34041	10N	-20+50	100	C174
5322 121 40323	100N	10	100	C175*
5322 121 40323	100N	10	100	C176
5322 122 34041	10N	-20+50	100	C177
5322 122 34041	10N	-20+50	100	C178
5322 122 34041	10N	-20+50	100	C179
5322 121 44137	68N	10	250	C180
5322 121 44137	68N	10	250	C181
5322 121 44137	68N	10	250	C182
5322 121 44137	68N	10	250	C183
5322 121 44137	68N	10	250	C184
5322 121 44137	68N	10	250	C185
5322 121 44137	68N	10	250	C186
5322 121 44137	68N	10	250	C187
5322 121 44137	68N	10	250	C188
4822 121 41161	150N	10	250	C189

VARIABLE CAPACITORS

Ordering number	Farad	Volts	Item
5322 125 54024	2-9P	300	C102

*) only instruments with serial prefix SM1

INTEGRATED CIRCUITS

Ordering number	Type	Item
5322 209 84825	MC10216P	IC101
5322 209 84304	SN75107AN	IC120
5322 209 84286	SN7451N	IC121
5322 209 84529	SN7403AN	IC122
5322 209 84528	SN7400N	IC123
5322 209 84722	GZF1201P	IC124
5322 209 84722	GZF1201P	IC125
5322 209 84227	SN7402N	IC126
5322 209 84655	723PC	IC150
5322 209 84183	SN74S74N	IC170
5322 209 84237	SN74S112N	IC171
5322 209 84724	SN74S64N	IC172
5322 209 80059	SN7475N	IC173
5322 209 84529	SN7403N	IC174
5322 209 84722	GZF1201P	IC175
5322 209 84722	GZF1201P	IC176
5322 209 85085	F34049PC SELECTED	IC177
5322 209 84227	SN7402N	IC178
5322 209 80072	SN7490AN	IC179
5322 209 80142	SN7442AN	IC180
5322 209 84723	DM8884A	IC181
5322 209 84976	ICF34001PC	IC182
5322 209 84183	SN74S74N	IC183
5322 209 84528	SN7400N	IC184
5322 209 84227	SN7402N	IC185
5322 111 94026	8X470K	IC190

TRANSISTORS

Ordering number	Type	Item
5322 130 44418	BF256A	TS101
5322 130 40378	2N918	TS102
5322 130 40542	BFX89	TS103
5322 130 40542	BFX89	TS104
5322 130 44435	2N5770	TS105
5322 130 40407	2N2369	TS120
4822 130 40973	BC557B	TS139
5322 130 24035	BT100A-300R	TS150
5322 130 40482	BRY39	TS151
4822 130 40855	BC337	TS152
5322 130 44417	BDX35	TS153
5322 130 40482	BRY39	TS154
5322 130 44418	BF256A	TS155
4822 130 40937	BC548B	TS170
5322 130 44247	BSS68	TS180
5322 130 44247	BSS 68	TS181
5322 130 44247	BSS 68	TS182
5322 130 44247	BSS 68	TS183
5322 130 44247	BSS 68	TS184
5322 130 44247	BSS 68	TS185
5322 130 44247	BSS 68	TS186
5322 130 44247	BSS 68	TS187
5322 130 44247	BSS 68	TS188

Ordering number	Type	Item
5322 130 30613	BAW62	GR101
5322 130 30613	BAW62	GR102
5322 130 30613	BAW62	GR103
5322 130 30613	BAW62	GR106
5322 130 30644	BA182	GR110
5322 130 30613	BAW62	GR120
5322 130 30613	BAW62	GR121
5322 130 34047	BAW62	GR122
5322 130 30613	BAW62	GR123
5322 130 30613	BAW62	GR124
5322 130 34297	BZX79-C10	GR151
5322 130 30594	BAV10	GR152

5322 130 34401	BZX70-C56	GR153
5322 130 30392	BZY88-C3V3	GR154
4822 130 30868	BY210-600	GR155
4822 130 30868	BY210-400	GR156
4822 130 30868	BY210-400	GR157
4822 130 30868	BY210-400	GR158
4822 130 30868	BY210-400	GR159
5322 130 34173	BZX79-C5V6	GR160
5322 130 30613	BAW62	GR161
5322 130 30192	BY126	GR163
5322 130 30414	BY164	GR167
5322 130 30613	BAW62	GR170
5322 130 34049	BZX75-C2V1	GR171
5322 130 30613	BAW62	GR172
5322 130 30613	BAW62	GR173
5322 130 30613	BAW62	GR175
5322 130 34257	BZX79-C51	GR179
5322 130 34189	BAV20	GR180
5322 130 34189	BAV20	GR181
5322 130 34189	BAV20	GE182
5322 130 34189	BAV20	GR183
5322 130 34189	BAV20	GR184
5322 130 34189	BAV20	GR185
5322 130 34189	BAV20	GR186
5322 130 34189	BAV20	GR187
5322 130 34189	BAV20	GR188
5322 130 34517	XC209A	GR189

INDUCTANCES

Ordering number	Description	Item
5322 158 10289	INDUCTANCE 0,68MH	L101
5322 158 10052	CHOKE	L102
5322 158 10311	INDUCTANCE 1MH	L103
5322 158 10052	CHOKE	L150
4822 526 10097	FXC BEAD	L151
5322 158 10052	CHOKE	L152

UNIT U2 PM6613

FIXED RESISTORS

Ordering number	Ohm	Tol.(%)	Type	Item
5322 116 54393	150	5	PR52	R201
5322 116 54396	68	5	PR52	R202
5322 116 54396	68	5	PR52	R203
5322 116 54431	162	1	MR25	R204
4822 111 30328	330	5	CR16	R205
4822 110 63125	4,7K	5	CR25	R206
4822 110 63147	33K	5	CR25	R207
4822 110 63098	470	5	CR25	R208
4822 110 63116	2,2K	5	CR25	R209
4822 110 63107	1K	5	CR25	R211
4822 110 63112	15K	5	CR25	R212
4822 110 63161	100K	5	CR25	R213
4822 110 63134	10K	5	CR25	R214
4822 110 63136	12K	5	CR25	R215
4822 110 63134	10K	5	CR25	R216
4822 110 63098	470	5	CR25	R217
4822 111 30309	560	5	CR16	R218
4822 111 30327	220	5	CR16	R219
4822 111 30347	680	5	CR16	R220
4822 111 30309	560	5	CR16	R221
4822 111 30327	220	5	CR16	R222
4822 111 30347	10	5	CR16	R223
4822 111 30331	470	5	CR16	R224
4822 111 30347	680	5	CR16	R225
4822 111 30324	100	5	CR16	R226
4822 111 30347	10	5	CR16	R227
4822 111 30323	270	5	CR16	R228
4822 111 30327	220	5	CR16	R229
4822 111 30269	1K	5	CR16	R230
4822 111 30309	560	5	CR16	R231
4822 111 30309	560	5	CR16	R232
4822 111 30328	330	5	CR16	R233
4822 111 30347	10	5	CR16	R234
4822 111 30323	270	5	CR16	R235
4822 111 30269	1K	5	CR16	R236
4822 110 63121	3,3K	5	CR25	R237
4822 110 63116	2,2K	5	CR25	R238
4822 110 63098	470	5	CR25	R239
4822 110 63103	680	5	CR25	R240
4822 110 63116	2,2K	5	CR25	R241
4822 110 63116	2,2K	5	CR25	R242
4822 110 63116	2,2K	5	CR25	R243
4822 110 63054	10	5	CR25	R244
4822 110 63098	470	5	CR25	R245
4822 110 63116	2,2K	5	CR25	R246
4822 110 63134	10K	5	CR25	R247

FIXED CAPACITORS

Ordering number	Farad	Tol.(%)	Volts	Item
4822 122 30128	4,7N	10	100	C201
4822 122 30128	4,7N	10	100	C202
4822 122 30128	4,7N	10	100	C203
4822 122 30128	4,7N	10	100	C204
4822 122 30128	4,7N	10	100	C205
4822 122 30043	10N	-20+80	63	C206
4822 122 30043	10N	-20+80	63	C207
4822 122 30043	10N	-20+80	63	C208
4822 122 30043	10N	-20+80	63	C209
4822 122 30043	10N	-20+80	63	C210
4822 122 31173	220P	10	100	C211
4822 122 31081	100P	2		C212
4822 122 31175	1N	10	100	C213
4822 122 31173	220P	10	100	C214
4822 122 31173	220P	10	100	C215
4822 122 31072	47P	2	100	C216
4822 122 30043	10N	-20+80	63	C217
4822 122 31173	220P	10	100	C218
4822 122 31175	1N	10	100	C219
4822 122 30043	10N	-20+80	63	C220

4822 122 31175	1N	10	100	C221
4822 122 31175	1N	10	100	C222
4822 122 31175	1N	10	100	C223
4822 122 31175	1N	10	100	C224
5322 124 14036	15M	-10+50	16	C225
5322 124 14079	68M	-10+50	6,3	C226
5322 124 14079	68M	-10+50	6,3	C227
4822 122 31175	1N	10	100	C228
4822 122 31175	1N	10	100	C229
4822 122 31072	47P	2	100	C231
4822 122 31175	1N	10	100	C232
4822 122 31175	1N	10	100	C233
4822 122 31072	47P	2	100	C234

INTEGRATED CIRCUITS

Ordering number	Type	Item
5322 209 84165	SN7474N	IC201
5322 209 84163	SN72741P	IC202
5322 209 84163	SN72741P	IC203
5322 209 84729	SP600B PLESSEY	IC204

TRANSISTORS

Ordering number	Type	Item
4822 130 40937	BC548B	TS201
5322 130 40745	BFW92	TS202
5322 130 40745	BFW92	TS203
5322 130 40745	BFW92	TS204
5322 130 44179	BFR90	TS205
5322 130 44435	2N5770 FAIRCHILD	TS206
4822 130 40937	BC548B	TS207
5322 130 40348	BC178B	TS208
5322 130 40343	BC108B	TS209

DIODES

Ordering number	Type	Item
5322 130 34364	BA379	GR201
5322 130 34364	BA379	GR202
5322 130 34283	HP5082-2835	GR203
5322 130 34283	HP5082-2835	GR204
5322 130 34364	BA379	GR205
5322 130 34364	BA379	GR206
5322 130 34364	BA379	GR207
5322 130 30613	BAW62	GR208
5322 130 34283	HP5082-2835	GR209
5322 130 34283	HP5082-2835	GR210
4822 130 30861	BZX79-C7V5	GR211
5322 130 30613	BAW62	GR212
5322 130 30613	BAW62	GR213
5322 130 34283	HP5082-2835	GR214
5322 130 34283	HP5082-2835	GR215

INDUCTANCES

Ordering number	Description	Item
5322 158 10222	INDUCTANCE 10MH	L201
5322 158 10222	INDUCTANCE 10MH	L202
5322 158 10243	INDUCTANCE 100MH	L203
5322 158 10311	INDUCTANCE 1MH	L204
4822 526 10025	FXC BEAD	L 205

MISCELLANEOUS

Ordering number	Description	Item
5322 265 54006	FEMALE CONNECTOR	BU201
5322 255 40089	TRANSISTOR HOLDER	

UNIT U2 PM6614

FIXED RESISTORS

Ordering number	Ohm	Tol.(%)	Type	Item
5322 116 54393	150	5	PR37	R201
5322 116 54396	68	5	PR52	R202
5322 116 54396	68	5	PR52	R203
5322 116 50417	162	1	MR25	R204
4822 111 30328	330	5	CR16	R205
4822 110 63125	4,7K	5	CR25	R206
4822 110 63147	33K	5	CR25	R207
4822 110 63107	1K	5	CR25	R208
4822 110 63125	4,7K	5	CR25	R209
4822 110 63152	47K	5	CR25	R210
4822 110 63107	1K	5	CR25	R211
4822 110 63138	15K	5	CR25	R212
5322 111 30399	33	5	CR16	R213
4822 110 63134	10K	5	CR25	R214
4822 110 63141	18K	5	CR25	R215
4822 110 63101	560	5	CR25	R216
4822 111 30264	2,7K	5	CR16	R217
4822 111 30323	270	5	CR16	R218
4822 111 30272	680	5	CR16	R219
4822 111 30245	47	5	CR16	R220
4822 111 30347	10	5	CR16	R221
4822 110 63161	100K	5	CR25	R222
4822 110 63116	2,2K	5	CR25	R223
4822 110 63125	4,7K	5	CR25	R224
4822 110 63134	10K	5	CR25	R225
4822 110 63098	470	5	CR25	R226
4822 110 63116	2,2K	5	CR25	R227
4822 110 63054	10	5	CR25	R228
4822 110 63103	680	5	CR25	R229
4822 110 63098	470	5	CR25	R230
4822 110 63116	2,2K	5	CR25	R231
4822 110 63125	4,7K	5	CR25	R238

FIXED CAPACITORS

Ordering number	Farad	Tol.(%)	Volts	Item
4822 122 31177	470PF	10	100	C201
4822 122 31177	470PF	10	100	C202
4822 122 31177	470PF	10	100	C203
4822 122 31177	470PF	10	10	C204
4822 122 30043	10NF	-20+80	63	C205
5322 122 34043	47PP	2	50	C206
4822 122 31175	1NF	10	100	C207
5322 124 14079	68MF		6,3	C208
4822 122 31043	3,9P	2	63	C209
4822 122 31173	220PF	10	100	C211
4822 122 31173	220PF	10	100	C212
4822 122 31177	470PF	10	100	C213
4822 122 30043	10NF	-20+30	63	C214
5322 124 14036	15MF		16	C215
4822 122 31175	1NF	10	100	C216
5322 122 34043	47PF	2	100	C217
4822 122 31072	47PF	10	100	C218
4822 122 30043	10NF	-20+80	63	C219
4822 122 31175	1NF	10	100	C220
5322 122 34043	47P	2	50	C221
4822 122 31175	1NF	10	100	C222
4822 122 31175	1NF	10	100	C223
5322 124 14079	68MF		6,3	C224
4822 122 30043	10NF	-20+80	63	C225
4822 122 31072	47PF	10	100	C226
4822 122 31173	220P	10	100	C227

INTEGRATED CIRCUITS

Ordering number	Type	Item
5322 130 44419	OM185 1C	IC201
5322 130 44419	OM185	IC202
5322 209 84721	PLESSEY SP670D-SEL	IC203
5322 209 84163	SN72741P	IC204
5322 209 84163	SN72741P	IC205
5322 209 84165	SN7474N	IC206
5322 209 84165	SN7474N	IC207

TRANSISTORS

Ordering number	Type	Item
4822 130 40937	BC548B	TS201
4822 130 40348	BC178B	TS202
5322 130 44179	BFR90	TS203
4822 130 40937	BC548B	TS204
5322 130 40343	BC108B	TS205

DIODES

Ordering number	Type	Item
5322 130 34364	BA379	GR201
5322 130 34364	BA379	GR202
5322 130 34283	HP5082-2835	GR203
5322 130 34283	HP5082-2835	GR204
5322 130 34364	BA379	GR205
5322 130 34364	BA379	GR206
5322 130 34364	BA379	GR207
5322 130 30613	BAW62	GR208
5322 130 34283	HP5082-2835	GR209
5322 130 34283	HP5082-2835	GR210
4822 130 30861	BZX79-C7V5	GR211

INDUCTANCES

Ordering number	Description	Item
5322 158 14119	COIL	L201
5322 158 14119	COIL	L202
5322 158 10276	INDUCTANCE 4,7MH	L203
5322 158 14119	COIL	L204
4822 526 10025	FXC BEAD	L205
4822 526 10025	FXC BEAD	L207
4822 526 10025	FXC BEAD	L208
4822 526 10025	FXC BEAD	L209
4822 526 10011	FXC BEAD	L210
5322 526 14019	BEAD	L211

MECHANICAL PARTS

Ordering number	Description	Item
5322 265 54006	FEMALE CONNECTOR	BU201
5322 462 34054	GUIDE RAIL	
5322 255 44082	IC HOLDER 14 PINS	
5322 255 40089	TRANSISTOR HOLDER	

UNIT U2 PM6615

FIXED RESISTORS

Ordering number	Ohm	Tol.(%)	Type	Item
5322 116 54393	150		PR52	R201
5322 116 54396	68		PR52	R202
5322 116 54396	68		PR52	R203
5322 116 50417	162		MR25	R204
4822 111 30328 M	330		CR16	R205
4822 110 63125 M	4,7K		CR25	R206
4822 110 63147 M	33K		CR25	R207
4822 110 63107 M	1K		CR25	R208
4822 110 63125 M	4,7K		CR25	R209
4822 110 63152 M	47K		CR25	R210
4822 110 63107 M	1K		CR25	R211
4822 110 63138 M	15K		CR25	R212
4822 111 30348 M	27		CR16	R213
4822 110 63134 M	10K		CR25	R214
4822 110 63141 M	18K		CR25	R215
4822 110 63094 M	330		CR25	R216
4822 111 30265 M	2,2K		CR16	R217
4822 111 30331 M	470		CR16	R218
4822 111 30312 M	4,7K		CR16	R219
4822 111 30327 M	220		CR16	R220
4822 111 30347 M	10		CR16	R221
4822 110 63161 M	100K		CR25	R222
4822 110 63116 M	2,2K		CR25	R223
4822 110 63116 M	2,2K		CR25	R224
4822 110 63134 M	10K		CR25	R225
4822 110 63098 M	470		CR25	R226
4822 110 63116 M	2,2K		CR25	R227
4822 110 63103 M	10		CR25	R228
4822 111 30272 M	680		CR16	R229
4822 110 63098 M	470		CR25	R230
4822 110 63116 M	2,2K		CR25	R231
4822 111 30324 M	100		CR16	R233
4822 111 30328 M	330		CR16	R234
4822 111 30328 M	330		CR16	R235
4822 110 63098 M	470		CR25	R236
4822 110 63069 M	39		CR25	R237
4822 110 63125 M	4,7K		CR25	R238

FIXED CAPACITORS

Ordering number	Farad	Tol.(%)	Volts	Item
5322 122 34024	470P	20	50	C201
5322 122 34024	470P	20	50	C202
5322 122 34024	470P	20	50	C203
5322 122 34024	470P	20	50	C204
4822 122 30043	10N	-20+80	63	C205
5322 122 34043	47P	10	50	C206
4822 122 31175	1N	10	100	C207
5322 124 14079	68M	-10+50	6,3	C208
5322 122 34043	47P	10	50	C209
4822 122 31173	220P	10	100	C210
4822 122 31173	220P	10	100	C211
4822 122 31173	220P	10	100	C212
5322 122 34024	470P	10	50	C213
4822 122 30043	10N	-20+80	63	C214
5322 124 14036	15M	-10+50	16	C215
4822 122 31175	1N	10	100	C216
5322 122 34024	470P	20	50	C217
5322 122 34042	12P	10	50	C218
4822 122 30043	10N	-20+80	63	C219
4822 122 31175	1N	10	100	C220
4822 122 30043	10N	-20+80	63	C221
5322 122 34043	47P	10	50	C222
5322 122 34024	470P	20	50	C223
5322 124 14079	68M	-10+50	6,3	C224
5322 122 34024	470P	10	50	C225
4822 122 31072	47P	2	100	C226
5322 122 34024	470P	20	50	C227
4822 122 31072	47P	2	100	C228
4822 122 30043	10N	-20+80	63	C229
5322 122 34043	47P	10	50	C230
4822 122 31054	10P	100V		C231

INTEGRATED CIRCUITS

Ordering number	Type	Item
5322 130 30419	OM185 SELECTED	IC201
5322 130 30419	OM185 SELECTED	IC202
5322 209 84725	SP616B PLESSEY	IC203
5322 209 84163	SN72741P TEXAS	IC204
5322 209 84163	SN74741P TEXAS	IC205
5322 209 84165	SN7474N TEXAS	IC206
5322 209 84165	SN7474N TEXAS	IC207
5322 209 84729	SP600B PLESSEY	IC208

TRANSISTORS

Ordering number	Type	Item
4822 130 40937	BC548B	TS201
5322 130 40348	BC178B	TS202
5322 130 44179	BFR90	TS203
4822 130 40937	BC548B	TS204
5322 130 40343	BC108B	TS205
5322 130 44435	2N5770 FAIRCHILD	TS206

DIODES

Ordering number	Type	Item
5322 130 34364	BA379	GR201
5322 130 34364	BA379	GR202
5322 130 34283	HP5082-2835	GR203
5322 130 34283	HP5082-2835	GR204
5322 130 34364	BA379	GR205
5322 130 34364	BA379	GR206
5322 130 34364	BA379	GR207
5322 130 30613	BAW62	GR208
5322 130 34283	HP5082-2835	GR209
5322 130 34283	HP5082-2835	GR210
4822 130 30861	BZX79-C7V5	GR211
5322 130 34364	BA379	GR212
4822 130 30861	BZX79-C7V5	GR213
5322 130 30411	BZX79-C3V9	GR214
5322 130 30411	BZX79-C3V9	GR215

INDUCTANCES

Ordering number	Description	Item
5322 158 14119	COIL	L201
5322 158 14119	COIL	L202
5322 158 10276	INDUCTANCE 4,7MICROH	L203
5322 158 14119	COIL	L204
5322 158 14119	COIL	L205
5322 158 14119	COIL	L206
5322 158 14119	COIL	L207
5322 158 14119	COIL	L208
5322 157 44024	COIL	L209
4822 526 10025	FXC BEAD	L210
4822 526 10025	FXC BEAD	L211
4822 526 10025	FXC BEAD	L212
5322 526 14019	FXC BEAD	L214

MECHANICAL PARTS

Ordering number	Description	Item
5322 265 54006	FEMALE CONNECTOR	BU201
5322 462 34054	GUIDE RAIL	
5322 255 44082	IC HOLDER 14PINS DIL	
5322 255 40089	TRANSISTOR HOLDER TO 18-3	

UNIT U1 (all models)
MECHANICAL PARTS

Ordering number	Description	Item	Qty.
5322 256 34031	FUSEHOLDER	VL150	2
5322 255 44082	I C HOLDER 14-PINS	D,I,L	1
5322 255 44107	I C HOLDER 16-PINS	D,I,L	1
5322 255 44112	I C HOLDER 18-PINS	D,I,L	5
5322 255 40089	TRANSISTOR HOLDER	TO18-3	10
5322 255 40089	TRANSISTOR HOLDER	TO18-4	2
5322 265 54006	TRANSISTOR HOLDER	TS153	1
5322 265 54006	FEMALE CONNECTOR	BU102	1
5322 265 54018	10-PIN CONNECTOR	BU102	1
5322 265 44064	CONNECTOR 10-PINS	BU103	1
5322 265 44064	CONNECTOR 10-PINS	BU104	1
5322 265 44064	CONNECTOR 10-PINS	BU105	1
5322 255 44107	FEMALE CONNECTOR	BU106	1
5322 265 54006	FEMALE CONNECTOR	BU107	1
5322 265 54006	FEMALE CONNECTOR	BU107	1
5322 273 84014	ROTARY SWITCH	SK105	1
5322 276 14117	PUSH BUTTON SWITCH SK104 SK107...SK109	SK103 SK111	7
5322 277 24006	SLIDE SWITCH	SK121	1
5322 263 64007	FEMALE CONNECTOR	SK131*	1
5322 268 14033	CONNECTOR PINS	SK131*	4

MISCELLANEOUS

Ordering number	Description	Item	Qty.
5322 146 14079	MAINS TRANSFORMER	T101	1
5322 142 64027	TRANSFORMER	T102	1
4822 253 20022	FUSE 1,6 A FAST	VL150	1
5322 462 34127	GUIDE RAIL FOR V1		6
4822 252 20001	THERMAL FUSE	VL101	1
5322 131 94027	DISPLAY ZM 1500-9	B101*	1
5322 131 94042	DISPLAY BR09253	B101	1
5322 535 94709	DISTANCE PIECE	FOR U2	2
5322 535 94711	DISTANCE PIECE	FOR OSC	1

REAR PANEL

Ordering number	Description	Item	Qty.
5322 265 30066	MAINS INPUT SOCKET	BU23	1
5322 267 10004	INPUT SOCKET C	BU24	1
5322 267 10004	OUTPUT SOCKET 10 MHZ	BU25	1
5322 121 44092	CAPACITOR 47NF 250V	C1	1
5322 290 40011	EXT BATTERY SOCKETS	BU21	2
5322 277 20077	INT,EXT,SWITCH	SK22	1

FRONT PANEL

Ordering number	Description	Item	Qty.
5322 456 14038	TEXTPLATE	PM6611	1
5322 456 14041	TEXTPLATE	PM6613	1
5322 456 14044	TEXTPLATE	PM6614	1
5322 456 14045	TEXTPLATE	PM6615	1
5322 450 64059	WINDOW		1
5322 414 34091	DISPLAY TIME KNOB	SK101	1
5322 414 14011	PUSH BUTTON KNOB SK104	SK103-SK107-SK111	7
5322 414 34091	SENSITIVITY KNOB	SK106	1
5322 414 34076	FUNCTION KNOB	SK105	1
5322 414 74015	COVER DISPLAY TIME KNOB	SK101	1
5322 414 74015	COVER SENSITIVITY KNOB	SK106	1
5322 414 74019	COVER FUNCTION KNOB	SK105	1
5322 267 10004	INPUT SOCKET A	BU1	1
5322 321 34205	INPUT SOCKET B	BU2	1

CABINET

Ordering number	Description	Qty.
5322 498 54048	HANDLE ARM	2
5322 498 54054	HANDLE PROFILE	1
5322 520 34164	BEARING BUSH	2
5322 414 64053	CAP HANDLE ARM	2
5322 447 84467	TOP COVER	1
5322 447 84466	BOTTOM COVER	1
5322 462 44181	REAR FOOT	4
5322 462 44179	BOTTOM FOOT	4
4822 462 70497	PLUG BOTTOM FOOT	4

*only serial number SM1

6. Test conditons

6.1. DC voltages.

The d.c. voltages in the circuit diagrams are typical and may vary slightly between instruments.
Unless otherwise stated the voltages are positive related to earth and measured without input signal. The test instrument can be analogue or digital with an input impedance of at least 40 kΩ/V.

NOTE. It is recommended to measure the d.c. voltages of the high-frequency input amplifier U2 of PM 6613, PM 6614 and PM 6615 with sampling oscilloscope PM 3400 and FET probe PM 9353.

6.2. Waveforms

Typical waveforms are shown at each section of the counter in which also the measuring conditions are mentioned.

6.3. Troubleshooting the power supply section

A fault in the power supply can be isolated easier if the counter circuits are disconnected by removing 10-pins connector BU 107. However, to simulate the load, a dummy load has to be fitted as shown in the figure. The dummy load can be assembled of the following components:

1 female connector 10 pins	5322 267 54102
1 carbon resistor 22Ω, 1 W	4822 110 23143
1 carbon resistor 220Ω, 1 W	4822 110 23089
1 carbon resistor, 18Ω, 2 W	4822 110 10061
1 carbon resistor, 56Ω, 0.5 W	4822 110 53074
1 carbon resistor, 5.6 kΩ, 0.5 W	4822 110 53127

CAUTION: + 120 V at pin 10 of the connector!





Figure XIII-1. Block diagram



Figure XIII-2. Component layout, unit 1

Testpoints 80 MHz input amplifier

The waveforms are recorded with a 50 MHz oscilloscope PM 3250 including passive 1:10 probe PM 9350 and with the counter set to FREQUENCY 10 Hz, self CHECK mode and min. DISPLAY TIME
Use figure XIII-2 to identify the location of the test points.

TP 1



Normal input signal to input amplifier at IC 101:13.
Oscilloscope settings
2 mV/div. and 50 ns/div. A.C. coupled.
Use 10 MHz OUT from the counter as trigger signal

TP 2



Inverted input signal to input amplifier at IC 101:15
Oscilloscope settings:
200 mV/div. and 50 ns/div.

TP 3



Normal input signal to input amplifier at IC 101:14
Oscilloscope settings
200 mV/div. and 50 ns/div
Use 10 MHz OUT from the counter as trigger signal

TP 4



Input signal to Schmitt-Trigger at IC 101:7.
Oscilloscope settings:
500 mV/div. and 50 ns/div

TP 5



TTL output signal at collector of TS 105
Oscilloscope settings:
1 V/div. and 50 ns/div



Figure XIII-3. Circuit diagram, 80 MHz input amplifier

Testpoints time base divider

The waveforms are recorded with a 50 MHz oscilloscope PM 3250 including passive 1:10 probe PM 9350 and with the counter set to FREQUENCY 10 Hz, self CHECK mode and min. DISPLAY TIME.
Use figure XIII-2 to identify the location of the test points.

TP 6



Time base divider input signal at IC 124:14.
Oscilloscope settings:
1 V/div. and 50 ns/div.

TP 7



Time base preset signal at IC 124:12.
Oscilloscope settings:
2 V/div. and 50 ms/div.

TP 8



Time base signal at IC 125:18.
Oscilloscope settings:
5 V/div. and 50 ms/div.

TP 9



Time base signal at IC 126:13.
Oscilloscope settings:
1 V/div. and 50 ms/div.

TP 10



Main gate signal at IC 183:6.
Oscilloscope settings:
1 V/div. and 50 ms/div.

TP 11



Display time triggering signal at IC 182:6.
Oscilloscope settings:
1 V/div and 50 ms/div.

TP 12



Display time sweep signal at IC 177:9.
Oscilloscope settings:
1 V/div. and 50 ms/div.

TP 13



Reset signal at IC 178:2.
Oscilloscope settings:
1 V/div. and 50 ms/div.



Figure XIII-4. Circuit diagram, time base divider

Testpoints decimal counting unit and display

The waveforms are recorded with a 50 MHz oscilloscope PM 3250 including passive 1:10 probe PM 9350 and with the counter set to FREQUENCY 10 Hz, self CHECK mode and min. DISPLAY TIME.
Use figure XIII-2 to identify the location of the test points.

TP 14



Gated input signal at IC 172:8.
Oscilloscope settings:
1 V/div. and 50 ms/div.

TP 15



Carry signal $1:10^5$ at IC 176:14.
Oscilloscope settings:
2 V/div. and 2 μs/div.

TP 16



Data A signal at IC 174:3 when last digit is zero.
Oscilloscope settings:
1 V/div. and 0.5 μs/div.

TP 17



Display clock signal at IC 177:15.
Oscilloscope settings:
1 V/div. and 50 μs/div.

TP 18



Display cathode signal at IC 181:16 when last digit is zero.
Oscilloscope settings:
20 V/div. and 0.2 ms/div.
Use signal at IC 179:11 as trigger signal.

TP 19



Display anode signal at cathode of GR 181.
Oscilloscope settings:
50 V/div. and 0.2 ms/div.
Use signal at IC 179:11 as trigger signal.

TP 20



Display blanking signal at collector of TS 139.
Oscilloscope settings:
1 V/div. and 0.2 ms/div.

TP 21



Transfer signal at IC 175:9.
Oscilloscope settings:
1 V/div. and 5 μs/div.



Figure XIII-5 Circuit diagram, decimal counting unit and display



Figure XIII-6. Circuit diagram, power supply



Figure XIII-7. Component layout, unit 2 PM 6613



Figure XIII-8. Circuit diagram. unit 2 PM 6613



Figure XIII-9. Component side, unit 2 PM 6614



Figure XIII-10. Soldering side, unit 2 PM 6614



Input Voltage at BU2	Input Freq at BU2	Measured Voltage
-40 dBm	200 MHz	-3 V
-20 dBm	200 MHz	+0.5 V
-10 dBm	200 MHz	+2 V

Figure XIII-11. Circuit diagram, unit 2 PM 6614



Figure XIII-12. Component side, unit 2 PM 6615

Figure XIII-13 Soldering side, unit 2 PM 6615



Figure XX-XX. Circuit diagram, unit 2 (XX-XX-X)

QUALITY REPORTING

CODING SYSTEM FOR FAILURE DESCRIPTION

The following information is meant for Philips service workshops only and serves as a guide for exact reporting of service repairs and maintenance routines on the workshop charts.
For full details reference is made to Information G1 (Introduction) and Information Cd 689 (Specific information for Test and Measuring Instruments).

LOCATION

□□□

Unit number
e.g. 000A or 0001 (for unit A or 1; **not 00UA or 00U1**)

or: Type number of an accessory (only if delivered with the equipment)
e.g. 9051 or 9532 (for PM 9051 or PM 9532)

or: Unknown/Not applicable
0000

COMPONENT/SEQUENCE NUMBER

□□□□□

Enter the identification **as used in the circuit diagram**, e.g.:

GR1003	Diode GR1003
TS0023	Transistor TS23
IC0101	Integrated circuit IC101
R0....	Resistor, potentiometer
C0....	Capacitor, variable capacitor
B0....	Tube, valve
LA....	Lamp
VL....	Fuse
SK....	Switch
BU....	Connector, socket, terminal
T0....	Transformer
L0....	Coil
X0....	Crystal
CB....	Circuit block
RE....	Relay
BA....	Battery
TR....	Chopper

CATEGORY

□

0 Unknown, not applicable (fault not present, intermittent or disappeared)
1 Software error
2 Readjustment
3 Electrical repair (wiring, solder joint, etc.)
4 Mechanical repair (polishing, filing, remachining, etc.)
5 Replacement
6 Cleaning and/or lubrication
7 Operator error
8 Missing items (on pre-sale test)
9 Environmental requirements are not met

Parts not identified in the circuit diagram:

990000	Unknown/Not applicable
990001	Cabinet or rack (text plate, emblem, grip, rail, graticule, etc.)
990002	Knob (incl. dial knob, cap, etc.)
990003	Probe (only if attached to instrument)
990004	Leads and associated plugs
990005	Holder (valve, transistor, fuse, board, etc.)
990006	Complete unit (p.w. board, h.t. unit, etc.)
990007	Accessory (only those without type number)
990008	Documentation (manual, supplement, etc.)
990009	Foreign object
990099	Miscellaneous

Sales and service all over the world

Alger: Sadetel; 41 Rue des Frères Mouloud Alger; tel. 656613–656607

Argentina: Philips Argentina S.A., Cassila Correo 3479, Buenos Aires; tel. T.E. 70, 7741 al 7749

Australia: Philips Electrical Pty Ltd., Philips House, 69-79 Clarence Street, Box 2703 G.P.O., Sydney; tel. 2.0223

België/Belgique: M.B.L.E, Philips Bedrijfsapparatuur, 80 Rue des Deux Gares, Bruxelles; tel. 02/13.76.00

Bolivia: Industrias Bolivianas Philips S.A. LA Jón postal 2964 La Paz tel. 50029

Brasil: S.A. Philips Do Brasil; Avenida Paulista 2163; P.O. Box 8681; Sao Paulo S.P.; tel 81–2161.

Burundi: Philips S.A.R.L., Avenue de Grèce, B.P. 900, Bujumbura

Canada: Philips Electronic Industries Ltd., Scientific and Electronic Equipment Division, Philips House, 116 Vanderhoof Avenue, Toronto 17 M 4G 2J1. tel. (416)-425-5161.

Chile: Philips Chiléna S.A., Casilla 2687, Santiago de Chile; tel. 94001

Colombia: Industrias Philips de Colombia S.A., Calle 13 no. 51-03, Apartado Nacional 1505, Bogota; tel. 473640

Costa Rica: Philips de Costa Rica Ltd., Apartado Postal 4325, San José; tel. 210111

Danmark: Philips Elektronik Systemer A/S Afd. Industri & Forskning; Strandlodsvej 4 2300-København S; Tel (0127) AS 2222; telex 27045

Deutschland (Bundesrepublik): Philips Elektronik Industrie GmbH, 2000 Hamburg 73, Meiendorferstraße 205; Postfach 730 370; tel. 6797-1

Ecuador: Philips Ecuador S.A., Casilla 343, Quito; tel. 239080

Egypt: Ph. Scientific Bureau 5 Sherif Str. Cairo – A.R. Egypt P.O. Box 1807; tel. 78457-57739

Eire: Philips Electrical (Ireland) Ltd., Newstead, Clonskeagh, Dublin 14; tel. 976611

El Salvador: Philips de El Salvador, Apartado Postal 865, San Salvador; tel. 217441

España: Philips Ibérica S.A.E., Avenida de America, Apartado 2065, Madrid 17; tel 2462200

Ethiopia: Philips Ethiopia (Priv. Ltd. Co.), P.O.B. 2565; Cunningham Street, Addis Abeba; tel. 48300

Finland: Oy Philips Ab, Postboks 10255, Helsinki 10; tel. 10915

France: Philips Industrie, Division de la S.A. Philips Industrielle et Commerciale 105 Rue de Paris, 93 002 Bobigny; tel. 830-11-11

Ghana: Philips (Ghana) Ltd., P.O.B. M 14, Accra; tel. 66019

Great Britain: Pye Unicam Ltd., York Street, Cambridge; tel. (0223) 58866

Guatemala: Philips de Guatemala S.A., Apartado Postal 238, Guatemala City; tel. 64857

Hellas: Philips S.A. Hellénique, 54, Ave Syngrou, Athens; tel 230476, P.O. Box 153

Honduras: Hasbun de Honduras Apartado Postal 83, Tegucigalpa; tel. 2-9121...5

Hong kong: Philips Hong Kong Ltd., P.O.B. 2108, St. George's Building, 21st floor, Hong Kong; tel. 5-249246

India: Philips India Ltd., Shivsagar Estate, Block "A", Dr. Annie Besant Road, P.O.B. 6598, Worli, Bombay 18; tel. 370071

Indonesia: P. T. Philips Development Corporation, Jalan Proklamasi 33, P.O.B. 2287, Jakarta; tel. 51985-51986

Iran: Philips Iran Ltd., P.O.B. 1297, Teheran; tel. 662281

Iraq: Philips Iraq W.L.L. Munir Abbas Building 4th Floor; South Gate. P.O. box 5749 Baghdad; tel. 80409

Island: Heimilistaeki SF, Saetún 8, Reykjavik; tel. 24000

Islas Canarias: Philips Ibérica S.A.E., Triana 132, Las Palmas; Casilla 39-41, Santa Cruz de Tenerife

Italia: Philips S.p.A., Sezione PIT; Viale Elvezia 2, 20052 Monza; tel. (039) 361-441; telex 35290

Kenya: Philips (Kenya) Ltd., P.O.B. 30554, Nairobi; tel. 29981

Malaysia: Philips Malaya Sdn Bhd. P.O. Box 332, Kuala Lumpur;/Selangor W. Malaysia; tel. 774411

Mexico: Philips Comercial S.A. de C.V., Uruapan 7, Apdo 24-328, Mexico 7 D.F.; tel. 25-15-40

Nederland: Philips Nederland B.V., Boschdijk, Gebouw VB, Eindhoven; tel. 793333

Ned. Antillen: N.V. Philips Antillana, Postbus 523, Willemstad; tel. Curaçao 36222-35464

New Zealand: Philips Electronical Industries (N.Z.) Ltd., Professional and Industrial Division, 70-72 Kingsford Smith Street, P.O.B. 2097, Lyall Bay, Wellington; tel. 73-156

Nigeria: Philips (Nigeria) Ltd., 6 Ijora Causeway, P.O.B. 1921, Lagos; tel. 45414/7

Nippon: Nihon Philips Corporation, P.O.B. 13, World Trade Center, 32nd Floor, Tokyo 105; tel. (03) 435-5211

Norge: Norsk A.S. Philips, Postboks 5040, Oslo; tel. 463890

Österreich: Oesterreichische Philips Industrie GmbH, Abteilung Industrie Elektronik, Triesterstrasse 64, A-1101 Wien; tel. (0222) 645511/31

Pakistan: Philips Electrical Co. of Pakistan Ltd., El-Markaz, M.A. Jinnah Road, P.O.B. 7101, Karachi; tel. 70071

Paraguay: Philips del Paraguay S.A., Casilla de Correo 605, Asuncion; tel. 8045-5536-6666

Perú: Philips Peruana S.A., Apartado Postal 1841, Lima; tel. 326070

Philippines: Philips Industrial Development Inc., 2246 Pasong Tamo P.O.B. 911, Makati Rizal D-708; tel. 889453 to 889456

Portugal: Philips Portuguesa S.A.R.L., Av. Eng.° Duarte Pacheco, 6 – Lisboa – 1

Rwanda: Philips Rwanda S.A.R.L., B.P. 449, Kigali

Saoudi Arabia: A. Rajab and A. Silsilah P.O. box 203 Jeddah - Saudi Arabia; tel. 5113-5114

Schweiz-Suisse-Svizzera: Philips A.G., Binzstrasse 15, Postfach 8027, Zürich; tel. 051-442211

Singapore: Philips Singapore Private Ltd. P.O. Box 340; Toa Payoh Central Post Office; Singapore 12; tel. 538811

South Africa: South African Philips (Pty) Ltd., P.O.B. 7703, 2, Herb Street, New Doornfontein, Johannesburg; tel. 24-0531

Sverige: Svenska A.B. Philips, Fack, Lidingövägen 50, Stockholm 27: tel. 08/635000

Syria: Philips Moyen-Orient S.A. Rue Fardoss 79 Immeuble Kassas and Sadate B.P. 2442 Damas; tel. 18605-21650

Taiwan: Yung Kang Trading Co. Ltd., San Min Building, Gnd Floor, 57-1 Chung Shan N Road, 2 Section, P.O.B. 1467, Taipei; tel. 577281

Tanzania: Philips (Tanzania) Ltd., Box 20104, Dar es Salaam; tel. 29571

Thailand: Philips Thailand Ltd., 283, Silom Road, Bangkok; tel. 36980, 36984-9

Turkey: Türk Philips Ticaret A.S., Posta Kutusu 504, Beyoglu; Gümüssüyü Caddesl 78/80 Istanbul 1 Turkye

Uganda: Philips Uganda Ltd. p.o. Box 5300 Kampala; tel. 59039

Uruguay: Industrias Philips del Uruguay, Avda Uruguay 1287, Montevideo; tel 915641 Casilla de Correo 294

U.S.A.: Philips Test and Measuring Instruments Inc.; 400 Crossways Park Drive, Woodbury, N.Y. 11797; tel. (516) 921-8880

Venezuela: C.A. Philips Venezolana, Apartado Postal 1167, Caracas; tel. 360511

Zaire: Philips S.Z.R.L., B.P. 1798, Kinshasa; tel. 31887-31888-31693

Zambia: Philips Electrical Ltd., Professional Equipment Division, P.O.B. 553 Kitwe; tel. 2526/7/8; Lusaka P.O. Box 1878

750101

For information on change of address:
N.V. Philips
Test and Measuring Instruments Dept.
Eindhoven - The Netherlands

For countries not listed:
N.V. Philips PIT Export Dept.
Test and Measuring Instruments Dept.
Eindhoven - The Netherlands